

Follow these steps to create a new Evergreen Technologies installation diskette for the Spectra upgrade:

NOTE: This is intended to be used with version 2.0 of the Spectra 333 CD. Version 2.0 of the Spectra 333 CD is blank beneath the words "Utilities CD" on the surface of the CD. Version 1.0 says Version 1.0 in this location. Some systems do not require the use of the CD.

- 1) The compressed install program is named SIV420.EXE. If this name has changed during email transport, rename the file to the correct name.
- 2) Place a floppy diskette in drive A:. This diskette does not have to be formatted, and it must not contain data that you wish to keep, since the data will be lost.
- 3) Double click the SIV420.EXE icon.
- 4) Select "Open" (not "Save to disk") if the option appears.
(The goal is NOT to save SIV420.EXE to the disk. The file is a self-extracting diskette archive, and the goal is to use the ".exe" program to create a new diagnostic diskette. In the process, the floppy diskette will be supplied with a set of system files so that you can boot from it.)
- 5) A box will appear requesting that you insert a floppy diskette.
- 6) If the floppy diskette you insert contains data, another box will appear informing you that this data will be lost.
- 7) Click OK.
- 8) When the transfer of the installation files to the diskette is complete, you can restart the computer
with the diskette in drive A:. The installation program will start automatically.
- 9) Please write "Evergreen Install Program 4.20" on the disk's label.
- 10) If the disk is used to update or upgrade a system's BIOS, then record this on the label as well.

NOTE: The latest Evergreen Spectra 333 install diskette can be obtained at the following location (URL):

<http://www.everttech.com/techsupport/Spectra/Spectrasupport.asp>