



EUV lithography NXE platform performance overview

Rudy Peeters

Contents

Roadmap

NXE:3100

NXE:3300B

Summary and acknowledgements

ASML EUV technology roadmap - extendibility

Extend NA 0.33 to below 10nm

Improved lens and illuminator performance

Imaging / Overlay performance match node requirements

Increased throughput at higher dose

| | | | | | | | | | |
|--------------------|----------------------------|--------------|--------------|------------------|----------|--------------------------|------------|--------|--|
| | | | | | | Under study | | | |
| Resolution/HP [nm] | | 32 | 27 | 22 | 16 | 13 | 10 | 7 | <7 |
| Wavelength [nm] | | 13.5 | | | | | | | |
| Lens | NA | 0.25 | | 0.33 | | | 0.33NA DPT | | |
| | flare | 8% | | 6% | | 4% | | >0.5NA | |
| Illumination | | coherence | | | | Extended Flex-OAI | | | |
| | | $\sigma=0.5$ | $\sigma=0.8$ | $\sigma=0.2-0.9$ | Flex-OAI | reduced pupil fill ratio | | | |
| Imaging | CDU [nm] | - | 2.0 | 1.7 | 1.3 | 1.1 | 1.0 | 0.9 | pupil fill defined by bright fraction of the pupil |
| Overlay | DCO [nm] | 7 | 4.0 | 3.0 | 1.5 | 1.4 | 1.2 | 1.0 | |
| | MMO [nm] | - | 7.0 | 5.0 | 2.5 | 2.0 | 1.7 | 1.4 | |
| TPT (300mm) | Dose [mJ/cm ²] | 5 | 10 | 15 | 15 | 20 | 20 | | |
| | Power [W] | 3 | 10 - 105 | 80 - 250 | 250 | 250 | 500 | | |
| | Throughput [W/hr] | - | 6 - 60 | 55 - 125 | 125 | 125 | 165 | | |



pupil fill ratio defined as the bright fraction of the pupil

ASML's NXE:3100 and NXE:3300B



| | NXE:3100 | NXE:3300B shipments started 2013 |
|--|---------------------------|--|
| NA | 0.25 | 0.33 |
| Illumination | Conventional 0.8 σ | Conventional 0.9 σ , 6 off-axis pupil settings |
| Resolution | 27 nm | 22 nm |
| Dedicated Chuck Overlay / Matched Machine Overlay | 4.0 nm / 7.0 nm | 3.0 nm / 5.0 nm |
| Productivity | 6 - 60 Wafers / hour | 55 - 125 Wafers / hour |
| Resist Dose | 10 mJ/cm ² | 15 mJ/cm ² |

Contents

Roadmap

NXE:3100

NXE:3300B

Summary and acknowledgements

NXE:3100 in use for cycles of learning at customers


6 systems operational at customers

Accumulated wafers exposed on NXE:3100




NXE:3100 shows stable performance

LONG TERM WAFER STABILITY OF 27nm V LS - NOV'12-APR'13, CONV.ILL. 14MJ/CM2, YIELDSTAR S200



FULL BATCH CDU UNIFORMITY OF 27nm LS

23 wafers, 83 fields/wafer, 1 point/field, Hitachi CG-4000



imec

Contents

Roadmap

NXE:3100


NXE:3300B

Summary and acknowledgements

EUV (NXE:33x0B) system status overview



- Multiple NXE:3300B systems fully qualified
 - 2 systems exposing wafers at the customer sites
 - Install has been started for 3 systems




-
- 6 more NXE:3300B systems being integrated
 - 4th generation NXE system (NXE:3350B) integration ongoing


-
- EUV cleanroom extension is under construction



Consistent and reproducible NXE:33x0B lens performance



lens NCE



Every bar is an individual lens

Data courtesy of Carl Zeiss SMT GmbH

Based on Zeiss input and does not include scanner contributions

NCE = Non Correctable Error

Contents


Roadmap

NXE:3100

NXE:3300B – OVERLAY


Summary and acknowledgements

Overlay improvements implemented on NXE:3300B



*wafer load grid
performance*



*wafer clamp
flatness*



*reticle clamp
flatness*



lens performance

Full wafer dedicated chuck overlay of $<1.4\text{nm}$



- Layers are exposed on the same wafer on the same chuck over multiple days
- Dedicated chuck overlay is a measure of the overlay performance of the system

Good full wafer matched machine overlay performance on multiple systems (NXE:3300B to immersion)



- Grid matching using different reticles
- Intrinsic design differences
 - Projection optics
 - Reticle clamping
 - Wafer clamping

Contents

Roadmap

NXE:3100


NXE:3300B – DEFECTIVITY

Summary and acknowledgements


The mask defect challenge

Challenging defect requirements on reflective EUV mask without pellicle

DUV Reticles (193nm)



EUV Reticles (13.5nm)



Current defectivity qualification test for particles on the front side of the reticle - particles per reticle pass (PRP)

Particle per Reticle pass test


Load reticle
into scanner




Pre-measure reticle



Cycle reticle/wafers




Take reticle
out of scanner



Post-measure reticle

- Reticles and wafers are cycled under exposure conditions without light therefore executable also in integration phase
- The test shows all particles that come onto the front-side of the reticle during the complete reticle cycle (off-line measurements / in-scanner cycling)
- Particles added during reticle handling outside the scanner system can not be excluded
- Particles on reticle level are not tested for printability on wafer level

System level testing for Particles Per Reticle Pass (PRP) is done simulating production use during integration at ASML



- Multiple NXE:3300B systems
- Measured at >92nm sensitivity
- During integration phase actions are done on the system which can lead to variations in test result
- PRP 100x test duration is ~20 hours

| | | | | | | | |
|-------------------|-----|-----|------|------|------|------|-----|
| # LOTS | 23 | 42 | 100 | 115 | 144 | 100 | 30 |
| # Wafers | 345 | 630 | 1500 | 1725 | 2160 | 1500 | 450 |
| Total # particles | 1 | 0 | 2 | 2 | 5 | 3 | 0 |

New imaging PRPi test focuses on printability of reticle defects on wafer level and excludes outside scanner reticle handling




The imaging PRP test


- Uses a location based analysis and provides information when a particle during the exposures gets onto the front side of the reticle
- Therefore, if a particle is generated in the system it can be determined when and where this particle has been generated

Early NXE:3300B test results from PRPi test are promising

System A





System B



- Early test performed on two systems using a test reticle (not a production reticle)
- **Repeated defects** (blue dots in the figures) observed already present during initial PRPi exposure
- Repeated defects are a combination of reticle absorber defects and multilayer defects, and particles already present on the reticle during initial exposure
- **No added defects** on frontside of the reticle found during simulated wafer exposures
- Extended build-up of statistics ongoing

Progress continues in EUV pellicle development

EUV Reticles (13.5nm)



First prototype full size free-standing pSi pellicle in progress

Contents

Roadmap


NXE:3100

NXE:3300B – PRODUCTIVITY

Summary and acknowledgements

MOPA Prepulse Source Architecture

- Key factors for high source power are:
 - High input CO₂ laser power
 - High conversion efficiency (CO₂ to EUV energy)
 - High collection efficiency (reflectivity and lifetime)
 - Advanced controls



MOPA - Master Oscillator Power Amplifier


Technology Demonstration: 70W power using MOPA+PP

Dose margin >3.5x reduced using advanced dose control


ASML

Public

Slide 24






- Plasma and gas-dynamic forces distort droplet trajectories causing energy instability
- Controls that compensate for all forces enable closed loop operation with reduced dose margin
- Dose margin is the difference between unstabilized open loop power and stabilized closed loop power



Industrialization: 30W EUV power on a production source



NXE:3300B MOPA+PP source operated in automated mode



- 30W dose controlled power, with 100% die yield (percentage simulated dies meeting the 0.5% dose repro specification)
- Results shown using ~18kW drive laser power
- NXE:3300B sources in the field have ~22kW drive laser power capability

Industrialization: Stable source operation is key

Dedicated test run: XE:3300B MOPA+PP source operating in automated mode for 6hrs continuously within dose spec. Fully automated for Fab operations



- Dedicated stability test run, slightly different settings and power as on previous slide
- 99.9% die yield (percentage simulated dies meeting the 0.5% dose repro specification)
- Stable source operation: Automation, start-up routines, recovery routines, diagnostics and closed loop controls in x, y, z, t and E


In-situ Collector Cleaning: Technology Proven

Significant improvement to COO and Availability

ASML

Public

Slide 27



- Reflectivity after cleaning compared to 'as new'
- Measurements on different reflectometers and sample locations

Full collector in-situ cleaning capability demonstrated with NXE:3300B compatible configuration

Contents


Roadmap

NXE:3100

NXE:3300B – FOCUS & IMAGING


Summary and acknowledgements

NXE:3300B full wafer focus uniformity <12nm



- The focus uniformity performance test is done in resist
- Focus sensitive marks are being exposed to obtain full wafer coverage information

3-day Focus Stability of 2.4nm on NXE:3300B




Focus Stability:


- 3-day Mean Focus range over both chucks
- Per wafer 16 fields are exposed
- 3-day Focus Stability of 2.4nm

Multiple systems show NXE:3300B CDU below 1.6nm dense and iso lines exposed at 16mJ/cm2


22 nm DL



22 nm IL



22nm dense and iso L/S with an exposure latitude of >14%





Conventional illumination

BE = 16 mJ/cm²

LWR = 3.8nm

Exposure Latitude > 14%

DoF > 100nm




Conventional illumination

BE = 16 mJ/cm²

LWR = 3.4nm


Exposure Latitude > 14%

DoF > 100nm




24nm regular contact holes (~18nm node DRAM) with conventional illumination *Large process window and 1.2nm FWCDU*

Process Window



Exposure latitude 18%
DoF > 120nm



Full wafer CD uniformity



Full wafer CDU: 1.2nm 3 σ

- Systematic fingerprints dominated by reticle and process
- Yieldstar measurements


NXE:3300B proximity matching performance




- Data shown with respect to average over 4 NXE:3300B's
- Per system intrafield CD measured through pitch on multiple fields on the wafer with the same test conditions (mask, resist, test layout)

- Average intrafield CD per pitch is then compared to population average
- Target performance for 22nm L/S is +/- 0.7nm
- Further improvement possible with optimized illumination

The NXE platform offers new concept off-axis illumination to enhance process window





- Flexibel and programmable illumination setting mechanism using fly's eye integrator




Simulations by Tachyon SMO NXE

16nm dense lines with >10% exposure latitude on NXE:3300B (dipole-90 setting)




16nm L/S
Dipole 90Y

Focus [nm]




Good logic tip-to-tip and tip-to-line performance at low doses

Tip-to-tip




Conv. 31nm

27nm Quasar




Tip-to-line




Conv. 20nm

19nm Quasar



EUV single-exposure enables aggressive shrink on 2D logic

shrink possible beyond 10nm Logic node requirement



Random logic metal layer user case

NXE:3300B enables single exposure with large DoF

EUV

- Node: Logic 10nm
- Single Exposure
- Conventional illumination
- DoF $\approx 120\text{nm}$

Position in the exposure slit

-12mm

0mm

+12mm



Good print performance over the full exposure slit



-80nm



-60nm



-40nm



-20nm



0nm



20nm



40nm



60nm




80nm


focus

EUV single exposure 10nm Logic metal layer


Feb 2013




- Low dose resist
- Conventional setting
- DOF of 60-80nm



EUV single exposure 10nm Logic metal layer



EUV single exposure 10nm Logic metal layer




Excellent process window for 10nm Logic metal layer

Low dose, off axis illumination, NXE OPC+

45nm pitch, Conv.


Dose ~45mJ/cm²



- > factor 2 dose reduction

45nm pitch, Q45

Dose ~20mJ/cm²



Contents

Roadmap




NXE:3100

NXE:3300B

Summary and acknowledgements

Summary

- **NXE:3100** in use for process and device development at customers
- **NXE:3300B** exposing wafers at customer sites
 - Multiple NXE:3300B system qualified and showing good imaging and overlay performance
 - Performance fit for customer development 10nm Logic and sub-20nm DRAM
 - Matched machine overlay (EUV to immersion) performance of <4nm shown on multiple systems
 - 70W MOPA-PP source power demonstrated with good dose control
 - Good defectivity performance shown on multiple systems at ASML in integration phase
 - Early results of new defectivity PRPi test show promising results
 - Progress continues in EUV pellicle development



First prototype full size free-standing pSi pellicle in progress

Acknowledgements

The work presented today, is the result of hard work and dedication of teams at ASML, Cymer, Zeiss, and many technology partners worldwide including our customers

Special thanks to our partners and customers for allowing us to use some of their data in this presentation