



# High Brightness Source Collector Module for EUV Mask Metrology

Kenneth Fahy, Fergal O'Reilly, Padraig Dunne and Paul Sheridan



**NewLambda  
Technologies**

Science Centre North  
UCD, Belfield  
Dublin 4, Ireland





# Outline

- Mask Metrology Requirements
- High Brightness SoCoMo
- LPP Source Characterisation
- The Collector
- Summary




# Metrology Source Considerations

Tool Requirements*		
Metrology Tool	Etendue	Brightness
AIMS	$5 \times 10^{-4} \text{ mm}^2\text{sr}$	30-100 W/mm <sup>2</sup> sr
Mask Blank	$4 \times 10^{-3} \text{ mm}^2\text{sr}$	> 80 W/mm <sup>2</sup> sr
Patterned Mask	$1.5 \times 10^{-2} \text{ mm}^2\text{sr}$	> 40 W/mm <sup>2</sup> sr

## Choices for etendue matching:

- Demagnify large source – photon loss for fixed etendue
- Magnify small source - higher photon collection  
- higher brightness for given input power




Magnifying ellipsoid (x8)  
Placed < 20 mm from EUV Source  
Etendue  $\geq 10^{-4} \text{ mm}^2\text{sr}$   
High Brightness



# High Brightness SoCoMo



- Size 1 X 1 X 1.5 m<sup>3</sup>
- High brightness LPP source
- Proprietary metal mixture
- Clean photons at IF
- Scalable (avg. power, brightness)
- Brightness roadmap to >1 kW/mm<sup>2</sup>sr





# High Brightness SoCoMo








# SoCoMo Characterisation Setup

## Lasers:

1. 50 Hz, 500 mJ, 25 W Nd:YAG
2. 5kHz, 125 W, 25 mJ, Nd:YAG


## Measurements:

- Plasma Size
- Source Spectra
- CE
- Debris
- Lifetime
- Stability







# Source Imaging




Mo/Si concave mirror  
1mm dia clear aperture  
Mag = 10.36

- 20 mJ laser input
- imaged at 13.5 nm




**Plasma FWHM of  
35μm observed**





# Source Imaging



Plasma size v laser pulse energy trade-off







# The Liquid Metal Collector



## Collector design example:

Coating GaInSn

Length = 100 mm


Large Diameter = 40 mm

Collection ~ 3%

## Optimising:

Collection efficiency




IF brightness







# EUV Test Data at IF - LPP

- GaInSn LPP source
- ~50 mJ on target
- Plasma size ~60  $\mu\text{m}$





# EUV Test Data - DPP




- $FWHM_x = 776 \mu\text{m}$ ,  $FWHM_y = 623 \mu\text{m}$
- *Zemax DPP source model*
  - Lorentzian pinch,  $FWHM = 420 \mu\text{m}$




# Latest Source Spectra

Nd:YAG, 15 mJ per pulse, 50 Hz



Nd:YAG, 17 mJ per pulse, 1 kHz




CE > 1% measured  
CE > 2% expected




# Latest Source Spectra

Nd:YAG, 15 mJ per pulse, 50 Hz




Nd:YAG, 17 mJ per pulse, 1 kHz







# Measurements at 4 kHz ....First Results..



- Demonstrated Source brightness  $> 100 \text{ W/mm}^2\text{sr}$
- CE, source size, stability under optimisation

# Brightness, Scalability, Reliability



- Smaller source sizes with next generation focusing optics
- Optimise CE @ 5 kHz
- Source and IF brightness measurements with 5kHz 125 W LPP
- Extend collector lifetime data using 125 W LPP
- Upgrade to 500 W laser for 1kW/mm<sup>2</sup>sr brightness



# Acknowledgements

- Enterprise Ireland TD-2009-0346
- Science Foundation Ireland 07/IN.1/I1771
- EUV Litho, Inc.
- ASML
- Larissa Juschkin (RWTH-TOS)
- Ralf Freiburger (ILT Fraunhofer)
- University College Dublin

# Thank you for listening!



**NewLambda**  
***Technologies***

**Contact:** Dr. Kenneth Fahy (CEO)  
[kenneth.fahy@newlambda.com](mailto:kenneth.fahy@newlambda.com)  
+353 87 8048670