
Discharge based EUV Sources for Metrology


Klaus Bergmann

EUV Source Workshop, October,9th, Dublin, Ireland


Overview

- Introduction
- Technology and current status of HCT sources at ILT
- Brilliance scaling for 13.5 nm
- Conclusions

History of EUV sources at ILT



AIXUV
EUV-Technology



PHILIPS

year 1997

2001

2003

2006


2011



Fraunhofer
ILT



PHILIPS



XTREME
technologies


USHIO
GROUP

P:\<ordner>name.ppt


Current XUV activities at ILT

- Development of sources for EUV lithography based on tin vacuum arc (together with Xtreme)
- Sources for metrology in the range soft x-ray and EUV
- XUV-Applications (Support of TOS, RWTH Aachen University)



X-ray microscopy



EUVL source development





Interference lithography



P:<ordner>name.ppt

Technical base: Philips HCT source

Philips Xenon Source



ASML α -demo Tool

PHILIPS

 **Fraunhofer**
ILT


- HCT principle was patented by ILT
- collaboration on power scaling for use as EUVL source
- source delivered first light in ASML α -demo tool
- currently used in the field as metrology source (mirror contamination, optics characterization)

Next Generation Source at Fraunhofer ILT

- technical base is the HCT source developed with Philips EUV
- new system allows for higher input power and pulse energy
- simplified and more compact source head design
- emission in the soft x-ray to extreme ultraviolet range
- increased electrode lifetime



Technical concept



- max. input power: 25 kW
- max. pulse energy: 20 J
- emission at 13.5nm: $>50 \text{ W}/(2\pi \text{sr } 2\% \text{b.w.})$
- typical plasma length: 3-5 mm
- accessible collection angle: $>80^\circ$

Scheme of electrode system



Selected examples of applications (1)

Absolute calibration of EUV diagnostics




Inband
Energy
Monitor

Inband Screen Tool




Grating / Normal Incidence Reflectometer

Ru-Mirror




ML-Mirror




Selected examples of applications (2)

Interference Lithography (11 nm)





Xe/Ar emission spectrum



X-Ray Microscopy (2.9 nm)





Nitrogen emission spectrum



PbS nanocrystals
for solar cells

Progress in Electrode lifetime



- erosion due to sputtering and cathode spots
- most critical consumable is cathode
- intermediate plate allows for reducing the influence of cathode erosion
- improvement by use of other metal
- envisioned interval for exchange of electrodes is 1Gshot

Cathode after 100 Mshot

Molybdenum




Metal with higher melting point



How do we measure “Peak Brilliance”

Emission profile ($r_{1/2}$, ζ)

pinhole camera
+ Zr coated silicon nitride window



$$f(r=0) = 1.0$$

$$\zeta = \frac{2 \int_0^{\infty} f(r) r dr}{r_{1/2}^2}$$

Inband power ($CE_{13.5\text{nm}}$)

calibrated energy monitor




f : repetition rate

E_{in} : electrical pulse energy

$$L_{peak} = \frac{f E_{in} CE_{13.5nm}}{\zeta \pi r_{1/2}^2}$$


Parameter studies (1): Brilliance Efficiency



- peak brilliance at 300 Hz operation
- red rhomb for old system at 8.7 kW
- demonstrated 2.0 W/(kW mm² sr) at a pulse energy of 6.1 J

Parameter studies (2): Variation of pulse energy

Normalized profiles for different energies





Brilliance efficiencies:
0.9 – 1.4 W/kWmm²sr

- peak brilliance at 1000 Hz operation
- low variation of profile coefficients over wide range of pulse energies

E_{in} / J	$r_{1/2} / \mu m$	ζ	$\zeta * r_{1/2}^2 / mm^2$
2.3	269	2.1	0.15
3.1	236	3.2	0.18
4.0	244	3.7	0.22
4.9	228	4.2	0.22
5.9	232	4.3	0.23
6.6	225	4.3	0.22
7.6	218	4.4	0.21
8.4	225	4.5	0.23



Demonstration of 21 W/(mm²sr)



$$L_{peak} = \frac{f E_{in} CE}{\zeta \pi r_{1/2}^2}$$

- f (repetition rate) : 3.3 kHz
- E_{in} (pulse energy) : 6.0 J
- CE (conversion eff.) : 0.3 %/2 π sr
- ζ (profile factor) : 5.8
- $r_{1/2}$ (radius) : 155 μ m

Demonstration of 21 W/(mm²sr)




$$L_{peak} = \frac{f E_{in} CE}{\zeta \pi r_{1/2}^2}$$

- f (repetition rate) : 3.3 kHz (2.5 kHz)
- E_{in} (pulse energy) : 6.0 J (7.0 J)
- CE (conversion eff.) : 0.3 %/2πsr (0.4 %/2πsr)
- ζ (profile factor) : 5.8 (4.8)
- $r_{1/2}$ (radius) : 155 μm (180 μm)

22.4 W/mm²sr

Scaling Potential >50 W/(mm²sr)

260 μm diameter source profile (full) and profile from 21 W/mm²sr demonstration (dotted)



- estimation of achievable brilliance by multiplying realistic and already demonstrated best of parameters
- experience with previous system: gas flow conditions is the key optimization parameter

20 kW

0.53 %


$$L_{peak} = \frac{f E_{in} CE}{\zeta \pi r_{1/2}^2} = 70.6 \frac{W}{mm^2 sr}$$

4.5



130 μm

Considerations on Source-Collector-Module

Normal Incidence collector (Ray Tracing)



- example for source-collector-module with typical distance:
~1m source-mirror and mirror-focus
- relaxed requirements for debris-mitigation
- homogeneous illumination of sample over ~50 μm “easy” to achieve



Intensity profile at IF

Conclusions

- next discharge source has been taken in operation at ILT
- technical base is status of development together with Philips EUV
- new system is more compact and covers a larger parameter range
- work on brilliance scaling just has started
- demonstration of **21 W/(mm² sr)** into 2%b.w. for 13.5 nm at 20 kW input power
- optimization potential for **>50 W/mm²sr** based on experimental data has been identified

Acknowledgements

- Markus Benk (currently at CXRO in Berkeley)
- Jochen Vieker
- Federal State NRW, Germany for financial support