

Recent Activities of the Actinic Mask Inspection using the EUV microscope at Center for EUVL

**Takeo Watanabe, Tetsuo Harada,
and Hiroo Kinoshita
Center for EUVL, University of Hyogo**

Outline

**1) EUV actinic mask inspection
using EUV Microscope**

**2) EUV Microscope using a high-
magnification objective with three
multilayer mirrors**

EUV actinic mask inspection using EUV Microscope

Takeo Watanabe, Tetsuo Harada, Hiroo Kinoshita,
Center for EUVL, LASTI, University of Hyogo

Tsuyoshi Amano, Osamu Suga,
*Selete**

**Present affiliation: EIDEC*



Outline

- 1) EUV microscope**
- 2) Phase defect observation**
- 3) Defect repairing using FIB and its observation**
- 4) Conclusions**

Background

Total 11 sets of the commercial steppers for EUV Lithography will be delivered in 2013 ~ 2014.

Mask pattern defect ➡ Electric circuit error ➡ Device error


EUV mask repair
and
the mask inspection for the repaired mask
is required

Mask inspection method

Inspection by exposure wavelength


EUV Mask Defect

Amplitude defect



Affected with
Intensity profile

Phase defect




Affected with
the phase
profile
(pit defect)


Pit and bump defects of 1-nm-depth
are printable.

Difficult to inspect using DUV and SEM.


EUV mask defect inspection tool




ALS
Zone Plate型



hp100 nm




NewSUBARU
Schwarzschild型




hp150 nm

EUV顕微鏡

Specification of EUV Microscope




Schwarzschild optics
Magnification : 30X
Numerical aperture: 0.3




- | | |
|-----------------------|-----------------------------|
| ▪ Light source | Bending magnet |
| ▪ Total magnification | 300 ~ 6000x |
| ▪ Resolution | 10 nm |
| ▪ Method | Bright field |
| ▪ Defect observation | Amplitude and phase defects |

Mask defect inspection by EUVM




150nm L/S

Absorber




Finished mask




Contamination

1um Dot




Blanks

Resolution of mask defect by EUVM



Isolated line of 300 nm width





Pattern edge profile of light intensity

By 25% and 75% of maximum light intensity light for the absorber edge pattern, the resolution of 50nm is obtained.

Printability of Mask Defect

Printability of phase defect under the absorber pattern




The printability depends on the position of the programmed defect.

400 nm L/S, programmed defect height of 12 nm

Hp 400 nm

Printability



Controlled the width and height of the programmed defect.


Depth: 1~4 nm

Width: 20~140 nm

The printability criteria was clarified using EUVM.



Printability of point and line programmed defects

Repair of clear defect




Conventional repairing method of clear defect by CVD

Clear defect
(Line-cut)




CVD film



Demerit:


- CVD layer contains carbon.
 - ➡ Thickness loss by cleaning.
- CVD layer has to be large height.
 - ➡ Affected with shadowing effect

Mask defect repair using FIB




By removing of the ML under the Clear defect by the Ga ion beam of FIB, the EUV light will not be reflected.

Pattern inspection by EUVM for the repaired clear defect by FIB



Pattern inspection by EUVM for the repaired clear defect by FIB



The clear defect which was repaired by FIB was observed using EUVM.

Conclusions

- 1) Printability criteria of the programmed defect width and height was obtained using EUVM mask defect inspection.
- 2) It is confirmed that the clear defect repairing by FIB is found to be usable using the EUVM observation.

Acknowledgement

This research was supported by NEDO.

And the mask sample was prepared by Selete.

EUV Microscope using a high-magnification objective with three multilayer mirrors

M. Toyoda, K. Yamasoe, T. Hatano, M. Yanagihara
Lab. of Soft X-ray microscopy, IMRAM, Tohoku University

A. Tokimasa, T. Harada, T. Watanabe, H. Kinoshita
LASTI, University of Hyogo



Outline

1. Motivation

Early studies and technical issues

2. Experimental

Innovative optics utilizing high-magnification

3. Highlight data

EUVL mask images with improved resolution

4. Summary and future plans

1. Motivation



Benefit of using high-magnification mirror as an objective

In the x-ray zooming tube, CsI thin film was utilized as the photoelectric conversion element.

However, the grain size of the CsI affected with the resolution of the EUVM imaging.

Thus the high-magnification-mirror objective is selected for the EUVM imaging.


At-wavelength inspection of EUVL mask




Requirements for an inspection tool

- ✓ At-wavelength observation ($\lambda=13.5\text{nm}$)
- ✓ High spatial resolution ($\delta<40\text{nm}$)
- ✓ Wide field of view for a rapid whole mask inspection

Early study: EUV Microscope on NewSUBARU



Line width 480nm
(120nm on wafer)



H. Kinoshita Jpn. J. Appl. Phys. **49**(2010)06GD07.

EUV⇒electron

✓ Bright field image at $\lambda=13.5$ nm

✓ Rayleigh's limit $\delta=30$ nm

Field of view $\Phi=20\mu\text{m}$

Actual resolution $\delta>100$ nm

Technical issues of the EUV Microscope

- ✓ **Degraded resolution** resulting from *aberrations of Schwarzschild objective.*
- ✓ **Small field of view**
limited by an electron lens of the zooming tube.


Aim of this work

Innovative EUV imaging facility realizing both

- ✓ **high spatial resolution** for 22-nm node mask,
- ✓ **wider field of view** for practical inspection time.

2. Experimental



Two-stage imaging system for high magnification




M.Toyoda, AIP Conf. Proc. 1365, 176(2011)

- ✓ Higher magnification ($m > 1200$)
 \Rightarrow ***30nm resolution with EUV-CCD camera***
- ✓ Good correction of off-axis aberrations
 \Rightarrow ***Large field of view over $\Phi > 160\mu m$***

Experimental setup of the novel facility




Instrumentation of the imaging optics



- ✓ Substrates (5 sets) were polished in IMRAM.
 - ✓ Mo/Si multilayer was coated with IBS.
 - ✓ Mirrors were aligned using Zygo interferometer.
- ⇒ Wavefront error $W=2.2 \text{ nm rms. (on-axis)}$


3. Highlight data

Confirmation of the magnification enhancement



Intermediate image (m=30)

Exp. time: 0.25 sec.



Final image (m=1460)


Line width: 240nm (60nm)

Exp. time: 36 sec.

EUV-CCD camera: pixel size 13.5μm, 2048 × 2048 pixels


Resolution measurement with L/S patterns

High magnification images ($m=1460$)



Line width: 225nm (56nm)



Exp. time: 10s



Line width: 88nm (22nm)

Exp. time: 100s

Resolution measurement with L/S patterns



- ✓ 88nm-width L/S pattern was clearly observed.
- ⇒ The capability of inspecting 22nm-node masks.

Conclusions

- 1) High-magnification of 1460x was achieved using three-mirror objective.
- 2) High-magnification enhancement was confirmed by the observation of the actinic EUV mask.
- 3) 88 nm mask pattern was observed using high-magnification objective in EUVM.

Summaries

- 1) Printability criteria of the programmed defect was confirmed by EUVM.
- 2) The benefit of the clear defect repairing method using FIB was confirmed by EUVM.
- 3) 88 nm mask pattern was observed using high-magnification objective in EUVM.