

# U.S. Regional Update

## 2013 International Workshop on EUV Lithography

Presented by Greg Denbeaux  
CNSE

# Resist-outgas testing at NIST


S. B. Hill, C. Tarrio, B. Berg, N. Faradzhev, S. Grantham and T. B. Lucatorto

- NIST resist-outgas testing update
  - 2 customer resists tested since SPIE (3/11/13)
  - 23 total customer resists tested to date
  - All have passed CG
  - None have shown significant non-cleanables with XPS
- Ongoing work
  - Scaling of outgas-test CG with time & resist dose
  - Identifying sources of inter-facility discrepancies
  - Optimizing & validating relevance of “non-cleanables” portion of outgas test
  - Verifying EUV / e-beam correlation for “non-cleanables”

# Three strategies to study non-cleanables


## Witness sample in resist outgassing

- EUV resists with S, F, I, ...
- Vary dose & time
- Record RGA




## Witness sample in admitted gases

- Species with S, F, I, ...
- Pure hydrocarbon
- Vary pressure & dose




## Spun films with specific chemistries: S, F, I, ...

Polymers designed with non-cleanable elements (S, F, etc) in specific chemical forms.



## AH cleaner *in situ* with XPS (coming soon)

XPS before and at regular intervals during AH cleaning.



## Characterization of EUV/e-beam exposures



- Composition: C & non-cleanables
- AH cleaning rates: C & non-cleanables
- Correlation with outgas RGA

# Magnetic Ion Mitigation and Hillock Formation <sup>4</sup>

## Magnetic Mitigation of High-Energy Ions in an EUV Source

Strong permanent magnet inserted in front of EUV source. Magnet modeled in COMSOL, particle trajectories simulated in MATLAB. Ionic output of source measured with Electrostatic Energy Analyzer (ESA). Experiment procedure below.

1. Without magnet, use ESA to measure head-on ion energy distribution function (IEDF).
  2. Given initial IEDF, Simulation predicts IEDF at various angles with magnet present.
  3. Magnet is inserted into chamber. IEDF is measured at an angle (35° shown) and compared to simulation.
- Simulation predicts strong mitigation, which is confirmed by experiment. **Simulation can be used for any magnet topology in any EUV source with quantifiable ionic output.**




## Hillock Formation on Sputtering Targets for EUV Mask Blanks

Hillocks form on sputtering targets for mask blanks; these hillocks later cause defects on deposited substrates.

Hillock formation was investigated as a function of incident ion angle and target material.

Hillocks appear to occur mostly on Si. When they appear on Ru targets, they are at locations of Si impurities on the Ru


Hillocks occur at larger ion angles for Si. In agreement with SRIM prediction:  $Y(\theta, E)/Y(0, E)$  increases with  $\theta$ .  
Can be removed by sputtering at 0° ion angle.




At left: Sintered Si surface,  $E=600\text{eV}$ ,  $\theta=75^\circ$  exposed for  $t=6$  hours.

# Sn Cleaning by Hydrogen Plasma Exposure <sup>5</sup>

Plasma produces H radicals, which bond to Sn and form  $\text{SnH}_4$  (gas).



Etching is increased with radical production. However, chamber size (and cleanliness) and substrate size are limiting factors, as  $\text{SnH}_4$  can dissociate upon collision and re-deposit.



## Plasma Parameters and Environmental Conditions:


Etching also measured as function of various parameters (pressure, flow rate, temperature, contamination, etc). Enough flow is needed to blow away  $\text{SnH}_4$  before it decomposes without blowing away too many H radicals. Higher temperatures lower etch rates, since  $\text{SnH}_4$  can more easily dissociate at higher temperatures. The only air contaminant to affect etching is oxygen, which eats up H radicals. Ideal plasma parameters: Low  $T_e$  (fewer dissociating collisions), High  $n_e$  (more radical production).

## Recent Experiments:


Full Etching of dummy collector demonstrated for 20nm and 50nm of Sn deposition. Etching measured on Si witness plates.

Etch Rates range from 0.75 nm/min to 1.33 nm/min, based on position ( $n_e$  changes based on position).

Etching removes Sn while not appearing to significantly roughen any exposed Si. SEMs from 20nm Experiment Witness Plate



(a) Deposited




(b) Etched

Backscattered Electron (BSE) detector detects material differences.

Etched portion of witness plate appears identical to bare Si. Masked portion (covered in Sn) is different.

BSE SEM from 50nm Experiment



# EUV REFLECTOMETER

- Recipient of 2005 R&D 100 award
- Installed for over 12 years worldwide
- Fully automated user friendly operation
- Continuously improving performance - Improved software, laser, and speed.



# EUV RESIST OUTGASSING TOOL



- Measures the contamination of optics from resist outgassing by using EUV (Extreme Ultraviolet) photon exposure, or alternatively by using electron beam (e-gun) exposure
- EUV Tech has successfully delivered 3 resist out-gassing tools.
- Two of them have been ASML certified
  - Third one in the certification process





# EUV HYDROGEN RADICAL CLEANER

- Streamlined witness sample transfer process between resist outgassing tool and hydrogen cleaner
- Cleaning rate ~ 3 nm/hour
- Small footprint 36" x 24"
- Controlled and interlocked N2 and H2 flow





# Evolution of Plasma Cleaning of Vacuum Chambers

- 1990's: Original development to decontaminate diffusion pump oil from electron microscopes
- 2000's: Plasma cleaning of SEMs becomes *de facto* standard for advanced e-microscopy
- 2011: XEI develops plasma cleaning system in form factor of TEM wand
- 2013: XEI Scientific delivers first plasma cleaning system designed specifically for EUVL applications



## Laser produced plasma sources for nanolithography—Recent integrated simulation and benchmarking

A. Hassanein and T. Sizyuk

*Center for Materials under Extreme Environment, School of Nuclear Engineering, Purdue University, West Lafayette 47907, USA*

(Received 22 March 2013; accepted 1 May 2013; published online 21 May 2013)

Photon sources for extreme ultraviolet lithography (EUVL) are still facing challenging problems to achieve high volume manufacturing in the semiconductor industry. The requirements for high EUV power, longer optical system and components lifetime, and efficient mechanisms for target delivery have narrowed investigators towards the development and optimization of dual-pulse laser sources with high repetition rate of small liquid tin droplets and the use of multi-layer mirror optical system for collecting EUV photons. We comprehensively simulated laser-produced plasma sources in full 3D configuration using 10–50  $\mu\text{m}$  tin droplet targets as single droplets as well as, for the first time, distributed fragmented microdroplets with equivalent mass. The latter is to examine the effects of droplet fragmentation resulting from the first pulse and prior to the incident second main laser pulse. We studied the dependence of target mass and size, laser parameters, and dual pulse system configuration on EUV radiation output and on atomic and ionic debris generation. Our modeling and simulation included all phases of laser target evolution: from laser/droplet interaction, energy deposition, target vaporization, ionization, plasma hydrodynamic expansion, thermal and radiation energy redistribution, and EUV photons collection as well as detail mapping of photons source size and location. We also simulated and predicted the potential damage to the optical mirror collection system from plasma thermal and energetic debris and the requirements for mitigating systems to reduce debris fluence. The debris effect on mirror collection system is analyzed using our three-dimensional ITMC-DYN Monte Carlo package. Modeling results were benchmarked against our CMUXE laboratory experimental studies for the EUV photons production and for debris and ions generation. © 2013 AIP Publishing LLC. [<http://dx.doi.org/10.1063/1.4807379>]

# Energetiq's Products



- High-brightness, long-life light source products
  - 1nm to 2000nm wavelength
- Product Applications
  - EUV Lithography and Metrology
    - ❖ Semiconductor Manufacturing
  - Soft X-Ray
    - ❖ Biological Imaging and Microprobe
  - UV/Vis/IR Imaging and Analysis
    - ❖ Spectroscopy
    - ❖ Inspection and Metrology



# EQ-10 EUV Product Line



Typical Performance*	EQ-10	EQ-10HR	EQ-10HP
Power 2 $\pi$ (13.5nm $\pm$ 1%)	10W	2W	20W
Plasma Size (FWHM)	400 $\mu$ m	1.6mm	400 $\mu$ m
Maximum Brightness	5W/mm <sup>2</sup> -sr	NA	8W/mm <sup>2</sup> -sr
Repetition Rate	2kHz	10kHz	2kHz
Plasma Size Stability ( $\sigma$ )	<4 $\mu$ m		<4 $\mu$ m
Spatial Stability Position( $\sigma$ )	<6 $\mu$ m		<6 $\mu$ m
Pulse-Pulse Stability	~2%		~2%

\*Performance values are typical. Actual values depend on customer's particular operating conditions which vary by application.

# UCSD's current activities support actinic metrology (13.5 nm) LPP light source development at KLA-Tencor

M. S. Tillack and A. J. Effenberger


- Nd:YAG lasers on Xe ice targets
- Main research thrust involves long-pulse performance (CE, DER size)
- Production of, and laser interactions with ice is a special challenge







# Results show similar emitter size and only 10-20% reduction in conversion efficiency for longer pulses

%CE vs lens position




DER image diameter vs lens offset





# 50W EUV Power with $\leq \pm 0.5\%$ Dose Stability

## MOPA Prepulse Mode of Operation

*Dose control within spec over 1 hour run*



Die Yield Exceeds 99.7%






## EUV ERC Overview

### Tabletop EUV Lasers




Two  
complementary  
compact source  
technologies

### High Harmonic Sources




- High Average Brightness
- High Rep Rate (1 – 100kHz)
- $\lambda = 3 - 30\text{nm}$

High resolution  
EUV printing with  
high sensitivity and  
low LER




### EUV Lithography Metrology

Measurement of mask –  
LWR, LER




Characterization of native  
defects on a full field mask




# EUV ERC Overview: Nanoimaging

## Compact Broad area EUV Microscopes



### TRANSMISSION


50 nm carbon nanotube




**Spatial resolution: 54 nm**  
**Image capture time: single laser shot**

### REFLECTION


Integrated Circuit






## Imaging



## Imaging of magnetic spin dynamics with Synchrotron Light






Sample:  $4 \times 4 \mu\text{m}^2$  PY element




# EUV ERC Overview: Nanoscale Materials Metrology


## Characterizing heat flow at the nanoscale





## Acoustic metrology of thin films



## Controlling reactions at the level of electrons




## Understanding charge transfer on catalytic surfaces, photovoltaics






# Development of multilayer projection mirrors for the first EUVL Micro-Exposure Tools with NA = 0.5 is underway

Opto-mechanical design of Projection Optics Box




M2 coating achieves  $\pm 0.04\%$  peak-to-valley variation and 0.033 nm rms added-figure error over 250.8 mm-diameter clear aperture



H. Glatzel, D. Ashworth, M. Bremer, R. Chin, K. Cummings, L. Girard, M. Goldstein, E. Gullikson, R. Hudyma, J. Kennon, B. Kestner, L. Marchetti, P. Naulleau, R. Soufli, E. Spiller, Proc. SPIE **8679** 867917 (2013).


# Triple-wavelength Mg/SiC multilayer coatings with corrosion barriers have been developed for EUV laser sources in the 25-80 nm wavelength region

Top-surface SEM image of standard Mg/SiC multilayer mirror with advanced corrosion




Spontaneously intermixed Al-Mg corrosion barriers enable use of Mg-based multilayers

Cross-sectional TEM image (topmost layers) of corrosion-resistant Mg/SiC multilayer



Measured at ALS beamline 6.3.2. (CXRO/LBNL) and at the GOLD facility (Instituto de Óptica, Madrid, Spain).



- R. Soufli, M. Fernández-Perea, S. L. Baker, *et al*, App. Phys. Lett. **101**, 043111 (2012).
- M. Fernández-Perea, R. Soufli, J. C. Robinson, *et al*, Optics Express **20**, 24018-24029 (2012).


# Rigaku Innovative Technologies (RIT)

Investing \$9M+ this year to establish & qualify scalable HVM EUVL Optic Pilot Production Facility – commissioning ~Oct 2013

- Second Generation Inline Deposition Tool,
  - In-house actinic metrology
  - cleaning/refurbishment facilities
- ~4000 ft<sup>2</sup> cleanrooms




Auburn Hills, MI



# RIT- Current Development Activities


## 1. Collectors for High Power Sources

- Volume Productivity
- Refurbishment of Used Optics; reduced CoO
- Cap Layer optimization
- IR mitigation



## 2. Illumination & Imaging Optics

- Refurbishment of Contaminated Optics
- High Gradient (NA) multilayers



## 3. R&D (basic)

- Increased reflectivity, 6.x




# New champion contact results



20nm CH; 10% Mask Bias

60nm Focus Increment


59.19mJ with 7% Dose Increment



	10% Mask Bias	20% Mask Bias
30nm CH	34.11mJ/cm <sup>2</sup>	27.75mJ/cm <sup>2</sup>
28nm CH	36.93mJ/cm <sup>2</sup>	27.58mJ/cm <sup>2</sup>
26nm CH	41.24mJ/cm <sup>2</sup>	30.43mJ/cm <sup>2</sup>
24nm CH	46.73mJ/cm <sup>2</sup>	33mJ/cm <sup>2</sup>
22nm CH	51.37mJ/cm <sup>2</sup>	36.07mJ/cm <sup>2</sup>
20nm CH	60.61mJ/cm <sup>2</sup>	41.76mJ/cm <sup>2</sup>
18nm CH	83.9mJ/cm <sup>2</sup>	64mJ/cm <sup>2</sup>

SEMATECH Berkeley MET  
Quadrupole illumination

# Characterization of large order asymmetry in high NA diffraction



- Effect well captured with rigorous 3D modeling including interface roughness term


# New SEMATECH-Berkeley mask inspection tool ( SHARP ) operational

150x faster  
2x higher resolution


65-nm hp  
(16.25)



60-nm hp  
(15.00)



55-nm hp  
(13.75)




# Rapid industry *Resist Learning Cycles* are critical to enable HVM EUV resist performance




## SEMATECH RMDC Materials & Wafer Processing Records

Materials Processed at RMDC



Wafers Exposed at RMDC




- >15000 materials and >29000 wafers have been processed at SEMATECH's Resist and Materials Development Center (RMDC) since 2008 (Albany MET & LBNL MET)
- In 2012, 4703 materials (1981 Albany MET, 2722 LBNL MET) and 7972 wafers were processed (3153 Albany MET, 4819 LBNL MET)

# L/S EUV Resist Performance Status

## *Pseudo PSM @ SEMATECH's Tool in Berkeley*



Performance against key metrics



	20nm	19nm	18nm	17nm	16nm	15nm	14nm	13nm
H 33.6mJ	19.3/4.3	18.4/3.5	17.6/3.7	16.4/3.9	15.1/3.7	14.7/3.7	12.5/3.8	
I 46.0mJ	15.3nm/3.9nm	16.1nm/4.2nm	15.8nm/4.3nm	14.5nm/4.0nm	13.1nm/3.6nm	11.6nm/4.2nm	11.3nm/4.5nm	
J 15.6mJ	19.2nm/4.8nm	18.5nm/4.3nm	17.7nm/4.4nm					
K 19.4mJ	19.2/6.2	17.8/4.9	17.2/4.1	15.6/4.9	14.7/4.7			
L 15.5mJ	20.7/4.8	19.6/6.0						
M 15.4mJ	21.1nm/4.2nm	19.9nm/4.5nm	18.3nm/4.8nm					



Best resist for each supplier

- Berkeley MET, PPSM
- 30nm Resist THK




# C/H EUV Resist Performance Status



SEMATECH Berkeley MET: Quad, NA 0.3,  
sigma 0.48~0.68;  
FT 80nm (A,B,C,F); 60nm; D, E  
No mask bias (A,B,C,F) (+20% Bias)

D\*, E\*: 60 nm FT & +20% bias




\* CDU was measured at 26nm HP

	26nm	24nm	23nm	22nm	21nm	20nm
A						59.5mJ/cm2 2.5nm
B						52.4mJ/cm2 2.4nm
C						36.3mJ/cm2 3.3nm
D*						33.5mJ/cm2 3.1nm
E*						21.0mJ/cm2 5.2nm
F						23.9mJ/cm2 3.0nm

# Mask Blank Defect Density Trend

Mask Blank Defect Density Trend (@73nm SiO<sub>2</sub> equiv.)



- 2015
  - Overall defect counts should meet requirements
  - Large size “Killer” defects still present
- HVM
  - Significant improvement needed to meet logic specifications
- Recent gains where made with the substrate
  - Reduction of cleaning induced defects
  - Substrate quality improvement at suppliers
- Process yields are not good




# SEMATECH – Zeiss AIMS™ collaboration

## Enabling EUV Mask Tool Infrastructure




- Zeiss AIMS™ EUV project started 05/2011 is on track
- Five EMI members are participating

### Concept Design



D.Hellweg, J.Ruoff, A.Herkommer, H.Feldmann, M.Ringel, U.Strößner, S.Perlitz, W.Harnisch, "Actinic aerial image review of EUV masks," Proc of SPIE 7969-15 (2011).




S. Perlitz, W. Harnisch, U. Strößner, J.H. Peters, M. Weiss, D. Hellweg,  
"Development status and infrastructure progress update of Aerial  
imaging Measurements on EUV Masks," BACUS 2011.

AIMS™ is a trademark of  
Carl Zeiss SMT AG.

# Nanodefekt Problem



## Nanodefekt Exist

Nanoscale materials structure generates nanosize problems



## Nanodefekt are hard to find


Below the threshold of most detection schemes



SEMATECH MBDC data


## Nanodefekt are difficult to characterize

Requires \$10'sM of difficult equipment




## Nanodefekt are difficult to remove

Nanoparticle forces are not microparticle forces




## Increasing pressure on yield learning



From S. Johnston, SEMATECH Japan Symposium 2012

## Increasing pressure on supply chain

Yield learning must continue but cost of doing so increases



# NanoDefects: The Solution



## Collaborate

Provide a common facility for the required critical expensive infrastructure



Defect inspection

Atomic force microscopy/  
scanning probe microscopy  
(AFM/SPM)

SEM+FIB+EDX


Transmission electron  
microscopy (TEM)

Auger electron  
spectroscopy (AES)




## Work Proactively

Break the problem down and solve component and material problems before integration




Component level  
accelerated life test



## Drive Solutions

Based on fundamental science of the defect problem



Understand the physics, model the problem, and make a solution

SEMATECH Nanodefekt Center