

Energy fraction of CO₂ laser absorbed in EUV source plasma

**Shinsuke Fujioka, Teruyuki Ugomori, Kensuke Yoshida,
Chaogang Li, Atsushi Sunahara^A, Katsunobu Nishihara,
Nozomi Tanaka, Hiroaki Nishimura**

Institute of Laser Engineering, Osaka University

^AInstitute for Laser Technology

Our research plan for >6% CE

- Radiation hydrodynamic simulation shows that only 50 – 70% of an incident CO₂ laser energy is absorbed even in a high-CE (3 – 4%) EUV source plasma. Laser absorption must increase for >6%
 - ← Non-absorbed laser energy will be measured with an integral sphere to validate the calculation by a radiation hydrodynamic simulation.
 - ← Angular distribution of non-absorbed CO₂ laser energy will be measured to identify the physical mechanism of laser absorption/scattering in a plasma.
- Measurement of absorbed CO₂ laser energy in a pre-expanded droplet
 - ← To validate enhancement of laser absorption in a long-scale rarefied plasma.
- Control of droplet expansion by changing laser pulse duration, wavelength, and irradiation geometry.
 - ← Measurement of density profile of a expanded droplet with CO₂ laser shadowgraph.
- Characterization of high-CE EUV source plasma
 - ← Measurement of density and temperature of high-CE EUV source plasma for benchmarking radiation-hydrodynamic code.

Facility upgrade

Pulse CO₂ laser (sub-J/100 ns) and pulse OPO laser (2 μ m-wavelength) are now installed.



Pulse CO₂ laser



GAM


**Wavelength: 9.3 μ m/10.6 μ m
(changeable)**

Energy/Duration: 650 mJ/100 ns

Repetition: single shot ~ 100 Hz

Near field pattern is controllable.

Pulse OPO laser



Coherent

**Wavelength 0.7 ~ 2.5 μ m
(tunable)**

Energy/Duration 25 mJ/4 ns @2 μ m

Repetition single shot ~ 10 Hz

Absorbed energy measurement

Only 40 – 70% of the incident CO₂ laser energy is absorbed even in a high-CE EUV source plasma.

Relation between absorbed energy fraction and EUV-CE


sim #	Condition	Laser abs.	EUV CE(%)
56	Confidential	40.2 (%)	2.49
59		50.2	3.21
60		49.4	3.25
61		50.9	3.30
62		62.0	4.15
63		72.0	3.77

Do we have a margin enough for 6%?

Absorbed energy measurement

**Absorption laser energy will be measured
with an integration sphere for CO₂ laser.**

Absorption fraction measurement with an Integration sphere




EUV-CE and absorption fraction can be measured simultaneously.

Absorbed energy measurement


Angular distribution of scattered CO₂ laser will be measured with themopile sensor array.

Themopile sensor



Piled thermocouple device
Sensitive only for 6.4 – 14 μm

Angular distribution measurement with themopile sensor array




Angular distribution is essential to identify scatter mechanism.


Optimization of droplet explosion

Density profile of CO₂ laser absorption region can be probed with a CO₂ laser shadowgraph.

Visible light shadowgraph @GP




1.2 keV x-ray shadowgraph @Osaka Univ.



“Pyrocam” detector will be used for CO₂ shadowgraphy.

CE, absorption, density, and temperature will be measured simultaneously **to establish guideline to >6%.**



Items	13 Q2	13 Q3	13 Q4	14 Q1	14 Q2	14 Q3	14 Q4	15 Q1	15 Q2	15 Q3	15 Q4
OPO laser	Install	Operation									
CO ₂ laser		Install	Operation								
Integral sphere	Design	Fab.	Install	Test	Operation						
Angular distribution	Design	Fab.	Install	Test	Operation						
Visible light backlight			Design	Install	Operation						
CO ₂ laser backlight				Design	Install	Operation					
Optimization of pre-expansion						Try & Error				Optimized	
High-Rep droplet						Design	Fab.	Intro		Operation	
Integration experiment										Experiment	