

Beam expander and homogenizer for 13.5 nm application

Ladislav Pina

Czech Technical University in Prague, Faculty of Nuclear Sciences and
Physical Engineering, 115 19 Prague 1, Czech Republic

Outline

- **Motivation**
- **Applications**
- **EUV/SXR sources**
- **Properties of LPP, DPP and FEL radiation**
- **EUV/SXR optics**
- **Collector optics for EUV lithography**
- **Beam expansion and homogenisation**


Motivation

- **Collector optics for EUV/SXR lithography**
- **Experimental tools for EUV/SXR lithography**
- **Diagnostic tools for EUV/SXR lithography**
- **Novel optical systems for EUV/SXR lithography**
- **Novel optical systems for EUV/SXR/XR microscopy**
- **Novel optical systems for EUV/SXR/XR tomography**

Applications

- EUV / SXR lithography
- EUV / SXR radiography
- EUV / SXR high contrast imaging
- EUV / SXR optics metrology
- EUV / SXR optics alignment


Electromagnetic radiation spectrum




D. T. Attwood *Soft X-rays and Extreme Ultraviolet Radiation: Principles and Applications* (Cambridge University Press, Cambridge, 1999)

13.5 nm – 92 eV

Laser Produced Plasma – solid (liquid) target



Ablation surface Critical surface




**Laser plasma parameters
for maximum EUV
emission**


$\sim 40 \text{ eV}, \sim 10^{19} \text{ cm}^{-3}$

Pinching Plasmas

Capillary Discharge Plasma



Main discharge unit




Charging circuit



- Ceramic Capacitors ($1.25 \div 31$ nF).
- Al_2O_3 capillary, 3.2mm dia., 20cm long.
- Low inductance \rightarrow high dI/dt .
- Pulse-charged: 1x Marx + coil.
- RL Rogowski coil.

Design and construction of new experimental capillary discharge apparatus (A. Jancarek, M. Nevrlka)
CTU Prague, Faculty of Nuclear Sciences



Laser Produced Plasma – gas puff target



- electromagnetic valve system





- X-ray backlighting images



H. Fiedorowicz *et al.* *Appl. Phys. B* 70 (2000) 305; Patent No.: US 6,469,310 B1
WAT, Warsaw



Synchrotron radiation



Characteristics of Synchrotron Radiation

- **High brightness:** synchrotron radiation is extremely intense (hundreds of thousands of times higher than conventional X-ray tubes) and highly collimated.
- **Wide energy spectrum:** synchrotron radiation is emitted with a wide range of energies, allowing a beam of any energy to be produced.
- **Synchrotron radiation is highly polarised.**
- **It is emitted in very short pulses, typically less than a nano-second.**

Synchrotron radiation





$$K = \frac{eB\lambda_u}{2\pi m_e c},$$

$K \gg 1$ wiggler

$K \ll 1$ undulator


Free Electron Laser radiation






FEL Radiation characteristics:

- Highest brightness of all laboratory sources
- Collimation
- Polarisation
- Coherence
- Emitted in very short pulses, typically femto seconds.

EUV/SXR/XR sources peak brilliance evolution



Diffraction and speckle patterns



Speckle pattern dependence on

- wavelength
- surface microroughness
- optical system geometry



surface microroughness \ll wavelength


Speckle pattern intensities
exponential distribution

$$P(I)dI = \frac{1}{\mu} \exp(-I/\mu)$$


FEL and plasma source comparison

Temporal pulse structure

SASE FEL (FLASH)



LPP Sn plasma



Optimization of high average power FEL for EUV lithography application

Akira Endo, Kazuyuki Sakaue, Masakazu Washio (Waseda University), Hakan Mizoguchi (Gigaphoton Inc.)


FEL Conference 2014 Basel, Switzerland

FEL and plasma source comparison

Spatial coherence


SASE FEL

~ 0.5



Plasma source

$\sim 3.2 \times 10^{-9}$



Optimization of high average power FEL for EUV lithography application

Akira Endo, Kazuyuki Sakaue, Masakazu Washio (Waseda University), Hakaru Mizoguchi
(Gigaphoton Inc.)

FEL Conference 2014 Basel, Switzerland


FEL and plasma source comparison

1. High divergence sources (LPP and DPP plasma sources)



Radiates in 2π steradian
ns – μ s pulses typ., but ...
Low repetition
Low spatial and temporal coherence

2. Low divergence (synchrotron, FEL, HHG, hot plasma laser)



Radiates in narrow beam
fs – ps pulses
High repetition
High spatial and temporal coherence

Next step – FEL as a EUV/SXR source for lithography

Subjects to be further studied:



- **Suppression of diffraction effects**
- **Suppression of speckle patterns**
- **Optics for quasi parallel input beam**
- **Sub micrometer IF**
- **High E field intensities phenomena with fs – ps pulses**
- **Photoresist exposure process physics with fs – ps pulses**

What optics is potentially relevant ?

- **Grazing incidence mirrors**
- **ML mirrors**
- **Multi foil mirror systems**


Kirpatrick-Baez system

- Double reflection X-ray Optics
- Two mirror sets vertical and horizontal
- Mirrors in both sets have to be curved parabolically
- Single focal point is formed in the intersection of the horizontal and vertical focal planes
- Quality of the focal spot depends on quality of substrates (shape, microroughness)
- Technology is not necessarily based on precise and expensive mandrel
- Classical manufacturing technology of laboratory KB optics is expensive





<http://imagine.gsfc.nasa.gov/>

Wolter system



Ellipsoidal Mirror

ELLIPSOIDAL MIRROR




Paraboloidal Mirror


Highly parallel beam (< 1 mr)

Large area

Hole in the middle





Beam profile




Multilayer optics

Multilayer Mirror




Montel system




<http://www.x-ray-optics.de>


Wolter system



Wolter systems




**Rotationally symmetric nested
mirrors Wolter system**



**2D mirrors nested
Wolter system**


<http://www.x-ray-optics.de>

Schwarzschild-optics



<http://www.x-ray-optics.de>




Polycapillary optics



<http://www.xos.com>



<http://www.ifg-adlershof.de>

Lobster Eye multifoil optics




Lobster eye & multifoil optics

- Wide FOV
- Glass and/or silicon substrate for soft X-rays
- Planar & ellipsoidal mirrors
- Foils 3x3 mm to 300x300 mm
- Foil thickness from 30 μm to 1 mm



Combined MFO – nested paraboloids X-ray optical system


- Non-functional (blind) central area of **Flower** system can be filled with thin rotationally symmetric foils (classical nested mirrors with parabolic shape)
=> improvement of Flower optical system aperture effective area for higher energies




- Patent pending (PV 2011-297)
- Advantages:
 - the largest effective aperture in SXR region
 - higher efficiency in XR region
 - precise expensive mandrels are not needed for Flower part (silicon or glass thin planar mirrors can be used)
- Application in X-ray telescopes, XRF analysis, EUV/XUV microscopy, tomography and EUV/XUV lithography, focusing of electrons/neutrons, ...

X-ray optical systems - comparison


- Size limited by the critical angle – the same maximum incident angle for all systems at a given photon energy
(reflectivity 70% after 1st reflection, 50% after 2nd reflection)
- Wolter I and KB systems have the same aperture size
- KBF system has more than two times larger aperture than the others



Wolter system




Kirkpatrick-Baez
system




Flower system

X-ray optical systems - comparison




=> COMBINATION
KBF and **P**
(in SXR - XR region)



Ray tracing – intensity map behind the LE mirror

Ray tracing – Homogenization of X-ray beam


Ray tracing – intensity map behind the LE mirror



LE Ray tracing – Typical intensity map just behind the mirror

EUVL Dublin 03-06 November 2014

Ray tracing – intensity map behind the LE mirror



INTENSITY MAP


LE-18

L = 6

X1 = 85

Xd = 90

Ray tracing – intensity map behind the LE mirror



INTENSITY PROFILE


LE-18

L = 6

X1 = 85

Xd = 90

Ray tracing – intensity map behind the LE mirror



INTENSITY MAP


LE-18

L = 6

X1 = 85

Xd = 200

Ray tracing – intensity map behind the LE mirror



INTENSITY PROFILE


LE-18

L = 6

X1 = 85

Xd = 200

Ray tracing – intensity map behind the LE mirror



INTENSITY MAP


LE-18 inclined

L = 6

X1 = 85

Xd = 200

Ray tracing – intensity map behind the LE mirror



INTENSITY PROFILE


LE-18 inclined

L = 6

X1 = 85

Xd = 200

Ray tracing – intensity map behind the LE mirror



INTENSITY MAP TRUE POSITION


LE-18 inclined

L = 6

X1 = 85

Xd = 200

Ray tracing – Homogenization of X-ray beam



INTENSITY MAP


LE-50

L = 6

X1 = 250

Xd = 750

Ray tracing – Homogenization of X-ray beam



INTENSITY PROFILE


LE-50

L = 6

X1 = 250

Xd = 265

Ray tracing – Homogenization of X-ray beam



INTENSITY MAP


LE-50

L = 6

X1 = 250


Xd = 750

Ray tracing – Homogenization of X-ray beam




INTENSITY MAP (11 mm detector sweep) LE-50 L=6 X1 = 250 Xd = 750

Ray tracing – Homogenization of X-ray beam




INTENSITY PROFILE (11 mm detector sweep) LE-50 L = 6 X1 = 250 Xd =
750

Ray tracing – Homogenization of X-ray beam




INTENSITY MAP (rotating LE mirror) LE-50 L = 6 X1 = 250 Xd = 750

Ray tracing – Homogenization of X-ray beam




INTENSITY PROFILE (rotating LE mirror) LE-50 L = 6 X1 = 250 Xd = 750

Ray tracing – Homogenization of X-ray beam



INTENSITY MAP (rotating LE mirror + sweeping detector) LE-50 L = 6
X1 = 250 Xd = 750

Ray tracing – Homogenization of X-ray beam




INTENSITY Profile (rotating LE mirror + sweeping detector) LE-50 L = 6
X1 = 250 Xd = 750

Ray tracing – intensity map behind the LE mirror

Homogenization of X-ray beam

Summary




Lobster Eye INTENSITY MAP

LE-50

L = 6

X1 = 250

Xd = 750




Lobster Eye INTENSITY MAP
(11 mm detector sweep)

LE-50

L = 6

X1 = 250

Xd = 750




Lobster Eye INTENSITY MAP
(rotating LE mirror)

LE-50

L = 6

X1 = 250

Xd = 750



Lobster Eye INTENSITY MAP
(rotating LE mirror + sweeping detector)

LE-50

L=6

X1 = 250

Xd = 750

Potential optical scheme for FEL based EUV lithography

Key components:

- Grazing incidence Kirkpatrick-Baez collector or better
- Axisymmetric ellipsoidal collector grazing incidence mirror
- Pinhole spatial filter at IF
- Optics for diffraction effects and speckle suppression (optional)
- Optics for beam homogenization (optional)
- Mask illumination optics
- Demagnifying imaging optics

Summary

- **Possible optical systems for FEL based EUV lithography were studied.**
- **Key features of FEL radiation were compared to LPP and DPP radiation**
- **Quasi parallel input beam, small beam size and possibly submicron size IF make potential optics solutions different from plasma source solutions.**
- **Diffraction effects and speckle suppression are needed.**
- **Homogenization of the beam was studied and one example of relevant optical system was modeled.**
- **Main building blocks of the FEL lithography optical system were identified.**

THANK YOU FOR ATTENTION



Prague

