

US Regional Update

Patrick Naulleau

Center for X-ray Optics

Lawrence Berkeley National Laboratory




2015 International Workshop on EUV Lithography, June 15-19, Maui, Hawaii



Source

- Cymer/ASML- LPP (8:40 Thu)
- Energetiq- DPP (10:20 Thu)
- Plex- DPP
- Colorado State- X-ray/EUV laser
- CU Boulder- HHG (4:10 Thu)
- Argonne, Berkeley, Fermilab, SLAC,...- FEL (1:00 Thu)
- Jlab- FEL
- SLAC, UCLA- Alt. accelerator sources (1:40 Thu, 2:00 Thu)
- Global Foundries- FEL requirements studies

Experimental setup




LPP produced with $\lambda = 1.03\ \mu\text{m}$ laser

- Diode array detector measures angular distribution of emission
- Grating spectrometer records spectral distribution


Gd spectral measurements

- Emission spectra broadens as pulse width is reduced from 2-4 ns to 0.1-0.2 ns
- Emission shifts to longer wavelengths as pulse width is reduced

Gd




S S Churilov, et al, Phys.
Scr. 80 045303 (2009)



Observed spectra compatible with ionization degree increasing towards Gd XIX

Gd plasma: spot size 50 μ m (f= 500 cm) and 25 μ m (f=100cm)




Conversion efficiency is largest for ns laser pulses


- Supercontinuum or isolated peaks
- Full spatial coherence to keV
- Femtosecond to Attosecond pulses
- Linear or circular polarization
- Unique new light source better than we dreamed of!



Nature Photonics 9, 99 (2015)
CLEO postdeadline JTh5C.1 (2015)




Broad coherent continuum OR Isolated single harmonic




Science 336, 1287 (2012); CLEO postdeadline FTh5A (2014)

Full spatial coherence: UV to soft X-ray



Science 297, 376 (2002)
Science 348, 530 (2015)


Femtosecond to attosecond pulses: UV to soft X-ray




PRL 111, 033002 (2013)
PNAS 111, E2361 (2014)

Controlling magnetic state via fast spin dynamics

PNAS **109**, 4792 (2012)
Nature Comm. **3**, 1037 (2012)
PRL **110**, 197201 (2013)
arXiv:1401.4101 (2014)




Controlling nanoscale energy transport



Nature Mater. **9**, 26 (2010)
PNAS **112**, 4846 (2015)

Angle-Resolved Photoemission (ARPES)


Mott insulator




Nature **471**, 490 (2011)
Nature Comm **3**, 1069 (2012)
PRL **112**, 207001 (2014)



Nano, energy science






Coupling to environment,
charge flow



Nano Lett. **13**, 2924 (2013)
JACS **137**, 3759 (2015)

Imaging at the λ limit



Optica **1**, 39 (2014); Science **348**, 530 (2015)

Commercial systems

www.kmlabs.com



Optics

- UI Urbana-Champaign- Collector cleaning (11:00 Wed)
- Rigaku- Multilayers (10:20 Wed)
- Berkeley Lab- Multilayers
- LLNL- Multilayers
- NIST- Optics contamination (10:40 Wed)
- CNSE- Optics contamination
- Zygo- High NA optics


In-Situ Plasma Cleaning of EUV Collector

Accomplishments during 2014-2015

- Illinois is conducting fundamental research to gain insight into H-radical plasma cleaning of EUV collector and feasibility of this technology for in-situ implementation
- Preliminary experiments conducted to measure etch rates as a function of flow and pressure
- Dummy collector cleaning demonstrated at source operating pressure
- Hydrogen radical density measurement accomplished



Current effort:

- Working towards establishing a predictive 3-D modeling for etch rate determination as a function of changing parameters, such as, pressure, temperature, radical density, geometry, flow path and deposition/re-deposition probabilities.
- Experiments are being set-up to obtain parameters towards the development of 3-D model





Cymer's 3100 source vessel is at Illinois at the Applied Research Institute. Industrial solution for tin cleaning is being researched.



Acknowledgements:



Multi-harmonic optics



Wavefront preserving EUV beamsplitters




Mask

- KLA- Patterned mask inspection (3:20 Thu)
- Berkeley Lab- High NA AIMS
- Berkeley Lab- Scatterometry/roughness (4:20 Thu)
- Photronics- Mask process
- Intel- Mask process (8:50 Wed)
- SEMATECH- Mask defects
- EUV Tech- Reflectometry


SHARP

*Freeform source
capabilities*



Ken Goldberg

0.625 effective NA demonstrated



FOURTH GENERATION EUV REFLECTOMETER


Rupert C.C. Perera

EUV Tech, Martinez, CA 94553 / www.euvtech.com / E-mail: rupert.perera@euvtech.com



LOCATION	PEAK REFLECTIVITY (ABS)	PEAK REFLECTIVITY PRECISION	PEAK WAVELENGTH (NM)	PEAK WAVELENGTH PRECISION (NM)
Absorber	1.49%	$3\sigma = 0.009\%$	13.553	$3\sigma = 0.0009\%$
Pattern Area	25.79%	$3\sigma = 0.05\%$	13.556	$3\sigma = 0.0009\%$
Black Border	0.035%	$3\sigma = 0.0032\%$	N/A	N/A
2x2mm High Reflectivity Window	61.25%	$3\sigma = 0.15\%$	13.553	$3\sigma = 0.0006\%$
4x4mm High Reflectivity Window	61.25%	$3\sigma = 0.10\%$	13.553	$3\sigma = 0.0006\%$



10 measurements on the same spot



Resist

- Inpria- Inorganic resists
- Oregon State- Inorganic resists (1:40 Wed)
- Cornell- Nanoparticle resists
- CNSE- Metal organic resists
- Berkeley Lab- Rad chemistry fundamentals,
Alt materials, Micro-exposure tools
- Georgia tech- Negative resists
- IBM- Alt. resist materials

13-nm patterning achieved in non-CA resist



60
mJ/cm²

LWR
= 3.1 nm





Oxide Nanoparticle EUV (ONE) Resists


Metal oxide cores: hafnium oxide, zirconium oxide, titanium oxide, etc.

- Reasonable EUV radiation absorbance
- High molecule density.


Carboxylic acid ligands: methacrylic acid, benzoic acid, etc.

- Enhance solubility in deposition solvents
- Lead to the solubility switch
- Affect sensitivity

	Ligands tested	
Decreasing speed ↓	1. DMA	} EUV tested
	2. Methacrylic acid	
	3. Isobutyric acid	
	4. Benzoic acid	
	5. Toluic acid	
	6. Nitrobenzoic acid	





Incorporating metals
with higher EUV
absorbance





Selection of Hybrid Nanoparticles

Hybrid
Nanoparticles




DMA--- Dimethylacrylic acid



EUV Sensitivity


2.2 mJ/cm²




MAA--- Methacrylic acid



4.2 mJ/cm²



BA--- Benzoic Acid





15 mJ/cm²



EUV radiation chemistry fundamentals


- Probe secondary electrons and mass spectra from EUV activated molecular beam
- Develop ab-initio models for radiation chemistry
- VMI tool built
- Initial measurements and modeling underway




4-Chloro 2-Methylphenol

MET5

- $NA = 0.5$
- Magnification = 5x
- Resolution limit = 8 nm
- Programmable pupil fill
- Field of view = $200 \times 30 \mu\text{m}$
- Mask angle of incidence = 6°
- Integrated wavefront metrology



Next generation lithography tool: waiting for delivery of optics



Thank You

