

Coherent diffraction imaging with partially coherent discharge plasma based EUV sources

Larissa Juschkin, Jan Bußmann, Raoul Bresenitz, Mikheil Mebonia
RWTH Aachen University and PGI-9, Forschungszentrum Jülich










Michal Odstrcil, William S. Brocklesby
University of Southampton

Yusuke Teramoto, BLV Licht- und Vakuumtechnik GmbH, Aachen

Marco Perske, Torsten Feigl, Optixfab GmbH, Jena

EUV group fields of research at RWTH/FZJ

- Applications of extreme ultraviolet radiation in nanostructuring and metrology including
 - ✓ EUV microscopy and imaging
 - ✓ EUV lithography and nanostructuring
 - ✓ Scatterometry and **coherent diffractive imaging**
 - ✓ Soft X-ray and EUV spectroscopy and reflectometry
 - ✓ Photo-electron emission spectroscopy and microscopy
- Soft X-ray and EUV compact radiation sources




Motivation – Why CDI is interesting for us?

CDI advantages comparing to standard optical microscopy:

- Not limited by quality of optics
- Large depth of focus
- More compact setup, easier alignment
- Better use of incidence light => lower dose
- Reconstruction of phase shift and attenuation

**particularly suited for
imaging with short
wavelength radiation**




**XUV: short wavelength
and strong light matter
interaction**



**lateral & in-depth (3d)
nm resolutions with
element sensitivity and
high throughput**


Reconstruction

- Knowledge of measured intensity and a compact object with known support allows iterative reconstruction
- Different algorithms can be used (ER, HIO, GHIO, ...) only changing the way data outside of the support is handled
- In each iteration step corrections for blurring, noise, etc. can be performed
- Error metric allows to see convergence of the reconstruction to a solution / minimum



Effect of limited coherence on diffraction pattern

- Diffraction patterns are only sharp if incident light is coherent




perfect coherence

- Object has to be compact and smaller than (half) the coherence width


$$N_{\text{pixel}} = \frac{\lambda}{\Delta\lambda} \cdot \frac{1}{O}$$

O: oversampling



spatial incoherence

- homogeneous blurring



temporal incoherence


- scaling from center

⇒ Use of apertures for spatial and multilayer mirrors for temporal filtering and accounting for blurring and bandwidth in reconstruction algorithm


- Cylindrical EUV emitting volume 150 – 750 μm
- Up to 3 kHz repetition rate with 2.3 J (FS-5420 up to 10 J) discharge energy
- Pulse length 10 – 100 ns
- Peak radiance:
 - $100 \frac{\text{W}}{\text{mm}^2 \text{ sr}}$ (@ 10.9 nm Xe/Ar, 2 kHz, 4% bandwidth, UTA)
 - $8 \frac{\text{W}}{\text{mm}^2 \text{ sr}}$ (@ 13.5 nm Xe/Ar, 1.5 kHz, 3.2% bandwidth)
 - $0.4 \frac{\text{W}}{\text{mm}^2 \text{ sr}}$ (@ 17.3 nm O, 2.5 kHz, <0.1% bandwidth)
- > 300 Mio. pulses before maintenance (depending on working gas)
- Small footprint (4 m²), simple maintenance and adjustment




*K. Bergmann, S. Danylyuk,
L. Juschkin, J. Appl. Phys.,
106 (7), 2009*





Typical emission spectrum GDP - Xenon



Typical emission spectrum GDP - Oxygen



- Scanning Coherent Diffractive Imaging
- Uses overlap information as real space constrain
 - Nyquist theorem requires an overlap of larger than 50% (in theory)
- Spatial incoherence does not influence field of view but scanning time
- Ptychography needs stable source during measurement
- Multi-wavelength reconstruction: $\psi_{tot} = \sum a_i |\psi_i|$




J. M. Rodenburg, H. M. Faulkner, "A phase retrieval algorithm for shifting illumination", *Applied Physics Letters* **85** (20), 4795 (2004)

Coherent imaging results with DPP source

– presented last year

@ 17.3 nm oxygen line


CDI



- Resolution ~ 200 / 110 nm
- 600 s – 1000 s exposure time

J. Bußmann, et al., SPIE Proceedings , 95890L (2015)

Ptychography




- Resolution ~ 250 nm
- Field of view ~ 25 μm x 25 μm
- Integration time ~ 30 s per position
- Recovery of refractive index
- Multi-wavelength reconstruction


*M. Odstrcil, et al., Opt. Lett. **40**, 5574 (2015)*

Ptychography with laser assisted industrial DPP source (BLV/Ushio)

- Liquid tin based EUV source by USHIO Inc.
- Up to $145 \frac{\text{W}}{\text{mm}^2 \text{sr}}$ radiance @9 kHz repetition rate
- Up to $300 \frac{\text{W}}{2\pi \text{sr}}$ in-band EUV power (w/o debris mitigation)





Y. Teramoto, et al., SPIE Advanced Lithography (2016)





Ptychography with laser assisted industrial DPP source (BLV/Ushio)

- Source radiance set to $36 \frac{\text{W}}{\text{mm}^2 \text{sr}}$
- Set of 2 ML mirrors for spectral filtering with
~ 5% transmission @ 13.5 nm and overall 2.2% BW
- Coherent photon flux density on sample $\sim 3 \cdot 10^3 \frac{\text{photons}}{\mu\text{m}^2 \text{s}}$
- 400 nm spheres on a 50 nm silicon nitride membrane
- 200 scanning positions each 30 s exposure time
- ~ 56 μm total field of view



Ptychography with laser assisted industrial DPP source (BLV/Ushio)


- Polyspheres are partly transmissive for 13.5 nm
- Phase and amplitude reconstructed
- 100 nm resolution
- Resolution is limited by radiant exposure (coherent photon flux density times exposure time)




- Used reconstruction code:
M. Odstroil, et al., Opt. Express **24**, 8360 (2015)
- Further Details:
J. Bussmann, et al., 2015 JARA-FIT Annual Report (2016)

Through focus propagation

- “Mimicking” through pellicle detection



Phase



Amplitude

- 3d reconstruction possible


Application of ptychography for detecting phase defects in multilayers

- Defects in ML mirrors may lead to a distortion of the image by introducing phase shifts and amplitude attenuation / defects on wafer
- Dark-field microscopy allows fast detection of defects, CDI / ptychography is able to reconstruct the phase and amplitude damage of the defect
- Fabrication and characterization of programmed defect arrays at the cleanroom HNF, Forschungszentrum Jülich
- Multilayer deposition at optiXfab. company
- Defect inspection at RWTH/FZJ

optiXfab.

Project aims on development of deposition techniques to fabricate defect-less multilayers

Supported by:



Programmed defect arrays fabrication at Helmholtz Nanoelectronic Facility (HNF)



HNF at Forschungszentrum Jülich

- Opened in 2013, 1000 m² clean room (Class 1-3), VDI DIN 2083, GMP and SIA
- User access to infrastructure
- Separate instruments / areas for II / IV, III / V and bio-hybrid microfabrication



Fabrication of defect array samples


- Defects are placed in / on standard silicon wafer
- Defect pit / bump height / depth of 20 nm
- Defect diameter from 10 μm – 30 nm
- Pits defined in a positive lithography step by e-Beam lithography and reactive ion etching
- Bumps created with chromium in a negative lithography step by e-Beam and RIE




Standard inspection techniques

www.hnf.fz-juelich.de

Helmholtz Nanoelectronic Facility




Visible light
microscopes




White light
interferometer




Fraunhofer
ILT



Scanning
electron
microscope



Atomic force
microscope




Focused ion
beam



- Blank mirror inspection
 - Dark field inspection (*L. Juschkin, et al. J. Phys. Conf. Ser. **186**, 012030 (2009)*), Scatterometry, Reflectometry (*S. Danylyuk, et al. Phys. Status Solidi **12**, 318–322 (2015)*)
 - ...
 - Blank and mask inspection (for lithography)
 - Characterization by resist-printed images, SHARP (*M. Benk, EUVL 2015, Maastricht*), Arial Image Measurement System (*Carl Zeiss AIMSTM*), ReScan II (*P. Helfenstein, et al., SPIE **97761F** (2016)*)
 - ...
 - Allow large field of view and high resolution but ...
 - Require synchrotron beamline or expensive large diameter, high quality optics
- ⇒ Development of a „cheap“ and „simple“ tool / schematic for EUV blank and mask inspection

Actinic inspection of multilayer defects with reflection ptychography



- Establishment of (near-field) reflection ptychography with an aspherical, high NA mirror at 13.5 nm
- Strongly curved illumination through 1 μm spatial filtering pinhole to achieve coherent illumination of 8 cm aspherical mirror in reasonable distance
- Variable bandwidth ($\frac{\Delta\lambda}{\lambda} < 2\%$) through double multilayer setup
- Due to setup delay, intermediate experiment on near-field ptychography was conducted



Nearfield ptychography with structured illumination



- Phase / amplitude response from the defects will be weak and sparse
- Stockmar et al.* proposed a method to achieve reliable ptychographic reconstruction even for weak scatterer
- Relaxed requirements on coherence and increased usage of detector size
- 40x de-magnified source image by Schwarzschild objective to achieve focus size of $\sim 10 \mu\text{m}$, strong Fresnel scaling due to high NA mirror and short distance to detector
- Pinhole acts as new light source and determines spatial coherence / final resolution
- Goal: $50 \mu\text{m}$ field of view with $50 - 100 \text{ nm}$ resolution

* M. Stockmar, et al.,
Scientific Reports, 3 (2013)





Near-field ptychography (with structured illumination)

- Standard TEM-grid was used as a dummy sample
- Run without diffusor
- Aspect ratio between EUV absorber and 70 nm pinhole limits light transmission below recognition level
- Test with larger „natural“ pinhole in absorber ($\sim 5 \mu\text{m}$)
- 190 images with 0.5 s exposure time and 1 s read out
- $\sim 10\times$ magnification of sample
- No scattering visible by eye



Nearfield ptychography

- Estimated resolution $\sim 2\ \mu\text{m}$
- Limited coherence due to pinhole size
- Reconstruction of illumination wavefront is feasible also with low-scattering sample and speckle-less pattern
- Reconstructed illumination wavefront can be used for adjustment of Schwarzschild objective
- *Measurements with smaller pinholes are work in progress*






Summary and outlook

- Successful utilization of discharge plasma sources for coherent imaging experiments
- Experimental demonstration of far- and near-field CDI and ptychography
- Application of ptychography with industrial tin-based LDP source
- Successful acquisition of phase information of nanoparticles on a membrane and of illumination wavefront

Future plans:

- Application of ptychography for detecting phase defects in multilayers
- Validation of the metrology technique with programmed defect arrays



Thank you very much for your attention!

