
High-Harmonic Generation for Metrology Applications

EUV Source Workshop, Dublin, November 7th 2017

J. Weitenberg,^{1,2} I. Pupeza,^{1,3} A. Ozawa,¹ T. Saule,³ J. Schulte,² H.-D. Hoffmann,²
Th. Udem,¹ P. Rußbüldt,² R. Poprawe,^{2,4} Th. W. Hänsch^{1,5}

¹Max-Planck Institute of Quantum Optics MPQ, Hans-Kopfermann-Str. 1, 85748 Garching, Germany

²Fraunhofer Institute for Laser Technology ILT, Steinbachstr. 15, 52074 Aachen, Germany

³Ludwig-Maximilian University Munich LMU, Faculty of Physics, Chair of Experimental Physics - Laser Physics, Am Coulombwall 1, 85748 Garching, Germany

⁴RWTH Aachen University, Chair for Laser Technology LLT, Steinbachstr. 15, 52074 Aachen, Germany

⁵Ludwig-Maximilian University Munich LMU, Faculty of Physics, Chair of Experimental Physics, Schellingstr. 4/III, 80799 München, Germany



MAX PLANCK INSTITUTE
OF QUANTUM OPTICS




High-Harmonic Generation for Metrology Applications – Outline

- High-harmonic generation (HHG) as a coherent EUV source
- Applications of HHG-sources
 - EUV frequency comb spectroscopy
 - Photoelectron spectroscopy
- HHG at high repetition rate
 - Enhancement resonators
 - Geometrical output coupling
- Laser systems to drive HHG
 - High-power amplifier
 - Nonlinear pulse compression



High-Harmonic Generation as a Coherent EUV Source



High-Harmonic Generation for Metrology Applications




Table-top coherent EUV / soft X-ray source:

- EUV frequency comb spectroscopy
- (Time-resolved) photoelectron emission spectroscopy
- Attosecond physics
- Microscopy, surface inspection, coherent diffractive imaging
- EUV lithography, direct structuring



High-Harmonic Generation for Metrology Applications




Table-top coherent EUV / soft X-ray source:


- EUV frequency comb spectroscopy
- (Time-resolved) photoelectron emission spectroscopy
- Attosecond physics
- Microscopy, surface inspection, coherent diffractive imaging
- EUV lithography, direct structuring

Photoelectron emission spectroscopy


<1 electron per EUV pulse to avoid
space-charge effects
large repetition rate improves signal



EUV Frequency Comb Spectroscopy



High-Harmonic Generation at High Repetition Rate



Enhancement resonator

Reach necessary intensity also at high repetition rates

Efficiency boost (~ 100) by recycling of non-converted driving radiation

Feasible for repetition rates $>10 \text{ MHz}$ (length $<30 \text{ m}$)


Resonator has to be locked to the incident frequency comb

Intensity clamping due to ionization ^[1]

Challenge: Output-coupling of harmonics from the resonator



High-Harmonic Generation at High Repetition Rate



Enhancement resonator

Reach necessary intensity also at high repetition rates

Efficiency boost (~ 100) by recycling of non-converted driving radiation

Feasible for repetition rates $> 10 \text{ MHz}$ (length $< 30 \text{ m}$)


Resonator has to be locked to the incident frequency comb

Intensity clamping due to ionization ^[1]


Challenge: Output-coupling of harmonics from the resonator



Geometrical Output Coupling with Hole Mirror




- Circulating fundamental mode and small hole ($\sim 100 \mu\text{m}$) in mirror behind focus.
- Harmonics have smaller divergence angle than fundamental radiation.
- Output coupling is more efficient for higher order harmonics.
- Harmonics with photon energy $>100 \text{ eV}$ at 78 MHz generated and coupled out ^[1].




Geometrical Output Coupling by Quasi-Imaging


- Degenerate resonator with an obstacle in the beam path
- Transverse modes are combined to avoid the obstacle
- On-axis intensity maximum at different position in the resonator
- »Simple slit mode« from Gauss-Hermite modes GH_{00} and GH_{40} (at middle of stability range)
- Small loss for circulating field at a broad opening ($<0.1\%$)
- Large output-coupling efficiency also for low order harmonics (estimated $>60\%$ @H17)



Intensity profiles in transverse direction of quasi-imaging at selected positions within the resonator (Rayleigh length z_R).





Slit mirrors and hole mirrors with sharp edges and small surface deformation manufactured by Inverse Laser Drilling ^[1].



High-Power Yb:YAG Innoslab Amplifier

Amplifier for He⁺ spectroscopy setup (MPQ):

- $P = 400 \text{ W} / 370 \text{ W}$ before / after isolator
- $P = 330 \text{ W}$ after spatial filter, $M^2 < 1.2$
- $\lambda = 1030 \text{ nm}$, $\Delta\lambda = 2 \text{ nm}$, $\tau = 0.85 \text{ ps}$



Key features of Innoslab amplifier ^{[1],[2]}

Thermal Management

- High average power
- Good beam quality
- Small depolarization

Folded beam path with beam expansion

- Constant saturation, high efficiency
- Uniform margin of intensity and fluence to damage thresholds
- Small B-integral, high pulse energy
- High gain (100-1000)




MAX PLANCK INSTITUTE
OF QUANTUM OPTICS


[1] P. Russbueldt et al., JSTQE 3100117 (2015).

[2] P. Russbueldt et al. Opt. Express 17, 12230-12245 (2009).

Nonlinear Pulse Compression




- Spectral broadening by Self-Phase Modulation (SPM) due to the Kerr effect, pulse shortening by subsequent chirp removal.
- Kerr effect goes along with self-focusing, which is compensated by the waveguide.
- Peak power limited to $P < P_{crit}$ (4 MW for fused silica) by self-focusing.




- Transition from a waveguide to a suitably designed lens duct overcomes self-focusing limit.
- Pulse compression at 1-100 μJ energy desirable (e.g. HHG at MHz repetition rate).
- Insensitive to variations of power, beam position and profile, and highly efficient (>90%)
→ suitable for high average power.
- Compact implementation with multi-pass cell (MPC).

Nonlinear Pulse Compression




- Transition from a waveguide to a suitably designed lens duct overcomes self-focusing limit.
- Pulse compression at 1-100 μJ energy desirable (e.g. HHG at MHz repetition rate).
- Insensitive to variations of power, beam position and profile, and highly efficient (>90%)
→ suitable for high average power.
- Compact implementation with multi-pass cell (MPC).


MPCSB Nonlinear Pulse Compression




- First demonstration of MPCSB scheme (2016) ^[1]:
Compression from $\tau = 880$ fs to 170 fs at 10 MHz, 37.5 μ J
- Setup for EUV frequency comb spectroscopy ^[2]:
Compression from $\tau = 860$ fs to 115 fs at 40 MHz, 7.5 μ J
- Setup for photoelectron spectroscopy ^[3]:
Compression from $\tau = 230$ fs to 35 fs at 18.5 MHz, 4.5 μ J
- High transmission for all setups ($T = 91\%$, 91%, 88%).
Beam quality preserved ($M^2 < 1.2$).



Comparison of Nonlinear Pulse Compression Schemes



EUV Power from HHG at High Repetition Rate



Summary & Outlook

- Many HHG-EUV applications afford / benefit from high repetition rate: EUV frequency comb spectroscopy, photoelectron emission spectroscopy.
- HHG at >10 MHz repetition rate affords enhancement resonator and/or high-power amplifier.
- Geometrical output coupling is an efficient and power-scalable scheme.
- Short pulses by nonlinear pulse compression increase HHG efficiency, MPCSB compression scheme allows compression for 1-100 μJ pulse energy at high power, is robust and efficient.
- Combining high-power amplifiers with nonlinear pulse compression will allow (resonator-assisted) HHG with mW EUV power at MHz repetition rate.

