

Public



Continued Scaling in Semiconductor Manufacturing with EUV Lithography

Anthony Yen

Vice President, Technology Development Centers

2018 EUVL Workshop, Berkeley, CA, 14 June 2018




2018



1984

EUV HVM introduction targeted at 7nm is supported by customer shipments and orders

Installed base of EUV systems is expected to double in 2018



TWINSCAN EUV product roadmap


Supports customer roadmaps well into the next decade

ASML

Public

Slide 4

2018 EUVL Workshop



3400B uptime improving to >90% for 2018/2019 HVM,
extending productivity to >150 W/hr @ 20 mJ/cm²



Productivity has been increasing

Secured EUV power is matched with increasing availability

$$\text{Productivity} = \text{Throughput}(\propto \text{EUV Power}) \times \text{Availability}$$


$$\text{EUV Power} = (\text{CO}_2 \text{ laser power} \times \text{CE} \times \text{transmission}) \times (1 - \text{dose overhead})$$

Source power from 10 W to > 250 W	Drive laser power	from 20 to 40 kW
	Conversion efficiency (CE)	from 2 to 6% (Sn droplet)
	Dose overhead	from 50 to 10%
	Optical transmission	
Source availability	Automation	
	Collector protection	
	Droplet generator reliability & lifetime	
	Drive laser reliability	

EUV 250W source industrialization

From proto to industrialized module in 1 year

Proto



Stand-alone Source
250 Watt demonstrated

Pre-Pilot

250W integrated on NXE:3400B
125 wph demonstrated




Industrialized module

Final industrialized 250W
source, completed Q4-17





← 1 Meter →



Enhanced laser-target isolation improves performance



Benefits of enhanced isolation:

- Higher, stable CO₂ laser power → lower dose overhead
- High conversion efficiency operation → higher pulse energy




EUV Source operation at 250W


with 99.90% fields meeting dose spec



Operation Parameters	
Repetition Rate	50kHz
MP power on droplet	21.5kW
Conversion Efficiency	6.0%
Collector Reflectivity	41%
Dose Margin	10%
EUV Power	250 W



Collector protection by hydrogen flow



Clever collector protection at 250W of source power has been found and is being implemented in the field


Two-fold approach to eliminate reticle front-side defects

ASML

Public
Slide 10

2018 EUVL Workshop

1. Clean system (without pellicle)




Reticle



2. EUV pellicle

EUV Reticle (13.5nm)




Reticle with pellicle





10x improvement for reticle defectivity in 2017

Further improvement to <1/10k expected in 2018



Productivity roadmap towards >125 WPH in place



Source power scaling continues to support productivity roadmap

Throughput of 140 WPH achieved at 246W

Matched and single machine overlay meet spec

ASML

Public



Slide 13

2018 EUVL Workshop



Overlay in spec at 125 WPH throughput

~200W power at IF with proto version SIM

DCO



MMO



Throughput of 140 WPH achieved at 246W

Actual:
195W
Target:
205W

Throughput without pellicle

125
WPH

Full field, 96 fields at 20 mJ/cm²

Actual:
246W
Target:
250W

Throughput without pellicle

140
WPH

>150
WPH

Road-
map

Full field, 96 fields at 20 mJ/cm²

Actual:
246W
Target:
250W

Throughput with pellicle+DGLm

>100*
WPH

125**
WPH

Target

Full field, 96 fields at 20 mJ/cm²


*Measured 116 WPH using pellicle with >83% transmission without DGL membrane. Throughput with membrane is calculated.

**Improvement plan for pellicle transmission to 88% and DGL membrane transmission to 90% included

3rd-gen. droplet generators: average lifetime ~780 hours


Weekly average service time

Performance parameter	Gen III
<u>Key Features</u>	Restart & Refill capable
<u>Run-time</u>	~780 hours (average) 2700 hours (max)
<u>Start-up yield</u>	>95%
<u>Availability</u>	95%
<u>Droplet diameter</u>	27 μm




50 Million measurements to reveal true histogram and failures **within 2 hrs**

Probability plot with Gaussian fit







Example of a missing hole




Hole clearing or closing



if the process were a continuum



If viewed sideways



Let's focus on closed holes (performed 10000 calculations per dose)



ASML

Public
Slide 17

2018 EUVL Workshop

Photon and acid counts in a hole cylinder* for all closed holes observed


As dose increases, hole closing is less and less due to low photon or acid counts

Data for 10000 holes





HCR

dose	avg CD	fract closed
30	14.88	0.0884
33	17.45	0.0136
36	19.46	0.0019
39	21.19	0.0002
42	22.74	0
45	24.15	0
48	25.45	0
51	26.69	0

closed holes





Results of 10000 calcs



* 15nm is approximate CD of holes where closing reaches ~10%


Local effects “beyond dose”



ASML

Public
Slide 18

2% flare, 55nm RT 2018 EUVL Workshop




Compare seed 58 with others


			#abs photons in cyl		# acids
stochastic seed	nom dose mJ/cm2	CD (nm)	27nm	15nm	15nm
58	30	0	961	378	1799
38	30	15.5	913	377	1845
43	30	13	971	401	1771

closed hole
fewer photons but open
fewer acids but open


seed 58



seed 38



seed 43



Local effects “beyond dose”

Spatial distribution of components determine hole closing near threshold dose


ASML

Public
Slide 19


2018 EUVL Workshop

developed
images


seed 58



seed 38





seed 43




latent
images

Blocked Polymer Concentration




No
dissolution
path to
bottom!

road block




De-blocked
polymer
profile gives
dissolution
path to
bottom




An idea (from Hansen) for extrapolation to low HCR

developed
images

Complex CAR model



Simplified direct photolysis
model with no quencher





Mechanism for closing is still
local fluctuations – lower
frequency variation with this
simpler, “more deterministic”
process

Plot of polymer blocking level at hole center



latent images

Blocked Polymer Concentration



No
dissolution
path to
bottom!

road block




Our findings on EUV resists

- Simulations show that hole closing is not simply explained by local dose variations
- Spatially dependent concentration variations (fluctuations) are also key
 - At a particular dose there will be a mean spatial distribution of blocked polymer with a random variation; every hole is different
 - Changing dose affects the mean level but not the fluctuation amplitude
- Two possible ways to reduce amplitudes of latent image fluctuations and hole closing rates:
 - “Simpler” and/or more uniform resist chemistry
 - Higher acid and/or quencher diffusion (but may limit resolution)






Phase-Control SMO

Optimization of source and mask to improve imaging robustness against phase effects from 3D masks and scanner aberrations




Phase-Control SMO: sensitivity analysis

- Must consider Zernike sensitivity of critical patterns



→ Select Z8, Z20 as most critical



Progression of EUV lithography for logic products

1st Generation (foundry 7-nm node)

$$k_1 \sim 0.45$$

Lithography process relatively straight forward with PC-SMO

The right time to perfect infrastructure

2nd Generation

$$k_1 \leq 0.4$$

Lithography process becomes more sophisticated

3rd Generation

$$k_1 \leq 0.3$$


Process sophistication; DTCO; Double patterning

4th Generation

0.55 NA

Larger NA results in higher effective throughput

NA limits # of LE steps and dose needed for LCDU








Quasar Illumination

ASML

Public

Slide 25

2018 EUVL Workshop



* Effective throughput = throughput / # LE steps

High-NA system architecture available

ASML

Public
Slide 26

2018 EUVL Workshop

Improved metrology

2~3x improvement in overlay/focus

Mask Stage

4x increase in acceleration

Lens & illuminator

- NA 0.55 for sub-10nm resolution
- High transmission

ASML

NXE:3400B

New Frames

Improved thermal and dynamic control with larger optics

Wafer Stage

2x increase in acceleration

Source

Compatible with 0.33 NA sources, power improvements opportunities over time




Stitching feasibility study ongoing


24nm dense holes successfully stitched on NXE:3300 at IMEC

First stitching experiments:

- 24nm Dense CH's
- Programmed offsets
- JSR 3030



Results for 3 different offsets:



Next steps:

- Determine process latitude
- OPC needed?
- Different structures

High-NA projection optics design available

Larger elements with tighter specifications



ASML

Public
Slide 28

2018 EUVL Workshop

Mask level

Wafer level


NA 0.33

NA 0.55

Extreme aspheres enabling
further improved wavefront / imaging performance

Obscuration enables
higher optics Transmission

Big last mirror driven by
High-NA





Long-lead items getting in place

Vessel parts are machined, 1st robots for large mirror handling




Chamber door and vessel






Outer mirror handling robot

High-NA system has smaller M3D effects than 0.33NA

Smaller mask angles of incidence thanks to higher mag and smaller CRAO




Two-bar trenches are a canary for M3D effects



Impact of M3D effects can be mitigated via SRAF's, M3D-aware SMO, thinner (high-k) absorber


- Using SRAF's
- Using M3D aware SMO



SRAF size adjusted per pitch:

- Horizontal: 20 – 56 nm @mask
- Vertical: 16 – 30 nm @mask


- Using a thinner (high-k) absorber




Sub-resolution assist features recover contrast loss from obscuration and reduce Mask3D overlay



L/S through resolution



L/S through resolution




SRAF size adjusted per pitch:

- Horizontal: 20 – 56 nm @ mask
- Vertical: 16 – 30 nm @ mask


High k absorber can increase contrast and reduce Mask3D overlay by ~2x for dipole test case



L/S through resolution




L/S through resolution



Alternative mask stack:

- 33nm high k material (Ni used)

Summary of RIE Etching of Ni



- Chlorine plasma was utilized to change metallic Ni to a surface layer of NiCl_2 , and removed with subsequent hydrogen plasma

Ernest Chen
UCLA



Customer commitment to EUV volume manufacturing continues

On 0.33NA Systems

- Shipped 3 systems in Q1 2018
- Received 9 orders in Q1 2018
- Planned to ship 20 systems in 2018
- Production capacity of at least 30 systems in 2019


On 0.55NA Systems

- Received 4 orders of R&D systems from 3 customers in Q1 2018
 - targeted to start shipping by end of 2021
- Sold options for 8 early volume systems in Q1 2018
 - targeted to start shipping in 2024


In-burst EUV power of 410 W

Demonstrated IF EUV pulse energy of 8.2 mJ at 50 kHz

Histogram EUV Pulse Energy




EUV Pulse Energy at IF



On a development EUV source at ASML San Diego
EUV bursts at 3% duty cycle

Droplet generator: principle of operation



Increasing
Droplet Generator
Pressure



Tin droplets at 80 kHz and at different applied pressures
Images taken at a distance of 200 mm from the nozzle

I would like to thank my ASML colleagues for all this work.
In particular, I thank Steve Hansen, Igor Fomenkov,
Roderik van Es, Jan van Schoot, Jo Finders, Hans Meiling,
and Stephen Hsu whose presentation material I used or
with whom I had fruitful discussions.

ASML

Thank you !