



EUV Materials Solution

Yoshi Hishiro
Director, R&D
JSR Micro Inc.
June 14, 2018

Contents


- What is Difference between EUV and ArF?
- EUV Material Development
 - Chemically amplified resist(CAR)
 - Sensitizer UL
 - Metal resist
- EUV Material Production
- Next Generation

Contents



- What is Difference between EUV and ArF?
- EUV Material Development
 - Chemically amplified resist(CAR)
 - Sensitizer UL
 - Metal resist
- EUV Material Production
- Next Generation

What is Difference between EUV and ArF Technology from Material Point of View?


Photo-resist patterning process



What is Difference between EUV and ArF Technology from Material Point of View?



- 1: Photon absorption
- 2: Acid generation



- 1: Photon absorption
- 2: Electron generation
- 3: Acid generation

How to Improve Resist Performance from View Point of Chemistry?

Process	<ul style="list-style-type: none">• Exposure• Acid generation	<ul style="list-style-type: none">• Chemical amplify reaction	<ul style="list-style-type: none">• Development
Key chemical	<ul style="list-style-type: none">• Absorption• Electron generation• Acid generation	<ul style="list-style-type: none">• Acid diffusion control• Active energy of protecting group• Uniformity of resist component	<ul style="list-style-type: none">• Dissolution rate• Dissolution contrast

Contents


- What is Difference between EUV and ArF?
- EUV Material Development
 - Chemically amplified resist(CAR)
 - Sensitizer UL
 - Metal resist
- EUV Material Production
- Next Generation

Resist Development for CH

- Pitch 44nm -

Exposed on NXE3300B

Current PAG/Polymer




Sensitivity: 36.8mJ/cm²
LCDU: 3.46nm

26% dose
Reduction



New short ADL PAG with
New high Tg polymer



Sensitivity: 27.2mJ/cm²
LCDU: 3.48nm


Development of new PAG/Resin enables breakthrough performance

Resist Development for LS

- Pitch 28 nm-


Exposed on NXE3300B

Best dose / best focus



Sensitivity: 55mJ/cm²
LWR: 3.8nm


Process window



Pitch 28nm can be resolved with reasonable LWR and process window.

Etch Transfer with JSR Tri-layer Stack


-Challenging for 30nm Pitch etch transfer to dielectric film-



30 nm Pitch Etch transfer have been succeed with JSR tri-layer stack

Sensitizer Under Layer for LS


- 32 nm Pitch -



Resist sensitivity is improved by applying "Sensitizer Under layer"
The possibility of 32 nm Pitch @ under 10mJ was observed.


Sensitizer Under Layer for CH

- 44 nm Pitch -



Sensitization was confirmed on CH and etch transfer have been demonstrated.

Motivation of Metal Nano Particle Resist




Potential Benefit of Metal resist

- High sensitivity
- High etching selectivity

Metal Nano Particle Resist Development

Exposed on NXE3300B



Resolution improvement was achieved by new Metal nano particle resist

Contents

- What is Difference between EUV and ArF?
- EUV Material Development
 - Chemically amplified resist(CAR)
 - Sensitizer UL
 - Metal resist
- EUV Material Production
- Next Generation

EUV Ready for the INDUSTRY


- EUV Resist Manufacturing & Qualification Center-

JSR partnered with imec enabling manufacturing and quality control of EUV lithography materials for the semiconductor industry.



Concept of EUV RMQC

- Foundry for EUV Photoresists -



Proximity is one of the advantages of EUV RMQC

Contents

- What is Difference between EUV and ArF?
- EUV Material Development
 - Chemically amplified resist(CAR)
 - Sensitizer UL
 - Metal resist
- EUV Material Production
- Next Generation

What is Next Generation?

$$\text{Resolution} = k_1 \frac{\lambda}{n \sin \theta}$$


$$= k_1 \frac{\lambda}{NA}$$

$$k_1 = 0.3$$

Technology	Wavelength h /nm	Resolution /nm	NA
g line	436	145	0.9
I line	365	122	0.9
KrF	248	83	0.9
ArF	193	64	0.9
ArF immersion	193	45	1.3
EUV (NA 0.33)	13.5	12	0.33
EUV (NA 0.5)	13.5	8	0.5
6.7 nm wavelength	6.7	4	0.5

Sub-10 nm Resolution


Need to consider polymer size



Mw 8000

Polymer size : 5-7nm

Need to consider resist absorption for 6.7nm wavelength



Chris A et. al , EUVL Symposium 2011

For sub 10nm resolution, new material development is required.

Summary

- Material solutions for EUV lithography
 - Chemically amplified resist(CAR)
 - Sensitizer under layer
 - Nano particle resist
- EUV material production
 - EUV RMQC
- Material development for sub 10 nm

